

Brand of TV

NO.	TV				
1	A MARK	574	579	033	
2	A.R. SYSTEM	026			
3	ABEX	145			
4	ACCENT	033	026		
5	ACCUSCAN	105			
6	ACTION	026	078	140	156
		169	171	172	173
		196	038		
7	ACURA	038			
8	ADMIRAL	032	136	033	128
		129	130	131	132
		133	134	153	146
		226	114	176	178
		201	141		
		127	005		
9	ADYSON	085	099	026	078
		140	156	169	171
		172	173	196	005
		015	021	057	084
		157	158		
10	AEA	026			
11	AEG	036			
12	AGASHI	018	020	031	033
		052	078	128	129
		131	133	134	141
		153	156	169	171
		173	196		
		019	026	038	053
		130	132	140	152
		172			
13	AGEF	127			
14	AIKO	033	026	226	125
		126	031	021	141
15	AIM	026	031	143	175
16	AIOSDTAY	226	038		
17	AIWA	225	085	099	226
18	AKAI	005	140	036	171
		057	018	143	046
		173	084	021	157
		052	196	125	168
		054	224		
		015	141	045	172
		078	020	156	048
		175	085	026	158
		053	198	126	169
		056	226		
		031	033		
19	AKF	005	015	021	057
		084	157	158	
20	AKI	018	020	052	053
		036	141		
21	AKIBA	038	026	078	140
		156	169	171	172
		173	196	018	020
		052	053	026	078
		140	156		
		144			
22	AKIRA	122			
23	AKITA	085	099		
24	AKITO	031	121	026	
25	AKTRON	038			
26	AKURA	038	018	020	052
		053	128	129	130
		131	132	133	134
		153	036	196	033
		173	141		
		026	025	144	172
		078	140	156	169
		171			
27	ALARON	058			
28	ALBA	005	109	036	134
		019	129	043	151
		026	131	053	153

Brand of TV

		033	133	085	169
		196	226		
		018	128	038	140
		020	130	052	152
		031	132	058	156
		172	173	099	171
		211			
29	ALBIRAL	001	009	018	020
		052	053	036	128
		129	130	131	132
		133	134	153	038
		019	152		
30	ALCYON	008	024		
31	ALHORI	036			
32	ALKOS	125	126		
33	ALLERON	582			
34	ALLORGAN	152	038	053	019
		152	073	018	020
		052			
35	ALLSTAR	026			
36	AMBASSADOR	006			
37	AMEX	036			
38	AMPLIVISION	151	036	143	175
		018	020	052	053
		019	152		
39	AMSTRAD	226	026	078	140
		156	169	171	172
		173	196	033	019
		152	005	141	028
		006	204		
40	ANAM NATIONAL	105	579	033	170
		026			
41	ANCONA	005	015	021	057
		084	157	158	
42	ANEX	036	128	129	130
		131	132	133	134
		153			
43	ANGELINE DESIGN	085	099		
44	ANGLO	226	033	141	
45	ANITECH	008	131	036	141
		024	133	078	152
		033	140	099	156
		171	173	226	169
		172	196		
		019	132	038	144
		026	134	085	153
		129	130	128	
46	ANSONIC	151	026	011	033
		005	090		
47	ANTECNO	038			
48	ANTIOPE	018	020	052	053
49	AOC	045	579	026	078
		140	156	169	171
		172	173	196	
50	APELSOUND	226			
51	APOLLO	046	048	054	056
52	AR SYSTEMS	019	152	026	078
		140	156	169	171
		172	173	196	
53	ARC EN CIEL	019	152		
54	ARCELIK	026	078	140	156
		169	171	172	173
		196			
55	ARCHER	579	033		
56	ARDEM	141	058	026	
57	ARISTONA	149	026		
58	ARKOS	123	124		
59	ARPHONE	005	015	021	057
		084	157	158	128
		129	130	131	132
		133	134	153	085
		099			
60	ARTHUR	107			
61	ARTHUR MARTIN	005	015	021	057

Brand of TV

		084	157	158
62	ART-TECH	038	036	226 031
63	ASA	007	009	013 032
		091	136	142 091
		024	107	026 114
		127	146	058
64	ASBERG	036	128	129 130
		131	132	133 134
		153	026	019 152
		031	008	024
65	ASORA	033		
66	ASTHON	036		
67	ASTRA	038	026	078 140
		156	169	171 172
		173	196	226
68	ASTRO SOUND	019	152	038 018
		020	052	053
69	ASUKA	005	078	021 141
		018	087	038 152
		020	140	053 157
		169	196	173 057
		158	171	
		015	084	026 144
		019	088	052 156
		172		
70	ATLANTIC	036	038	026 011
71	ATLANTIS	038		
72	ATORI	226	038	033
73	AUCHAN	005		
74	AUDIOSONIC	005	141	033 158
		084	018	151 038
		171	129	020 153
		053	173	131 026
		157	078	
		015	147	036 169
		128	019	152 052
		172	130	021 156
		057	196	132 133
		134	140	
75	AUDIOSTAR	018	020	052 053
		038		
76	AUDIOTON	026	078	140 156
		169	171	172 173
		196	036	038 128
		129	130	131 132
		133	134	
		019	152	151 141
		153		
77	AUDIOVOX	105	579	
78	AURORA	033	019	152
79	AUSIND	008	024	007 091
		038		
80	AUTOVOX	003	007	049 015
		075	076	097 134
		024	091	114 041
		591	172	173 196
		008	171	
		127	146	026 078
		140	156	169
81	AWA	033	140	141 169
		607	043	109 033
		110	026	198
82	AXANE	036	019	152
83	AXION	018	020	052 053
84	AXXENT	033		
85	BAIRD	226	005	015 021
		031	084	157 158
		143	175	057 122
86	BANG & OLUFSEN	127	087	088
87	BARCO	019	152	005
88	BARCOM	026	078	140 156
		169	171	172 173
		196		
89	BASIC LINE	005	078	018 140

Brand of TV

		021	156	033 158
		038	171	053 173
		036	169	052 172
		057	196	
		015	084	020 144
		026	157	
90	BASTIDE	019	152	038
91	BAUER	036		
92	BAUR	005	084	018 117
		021	119	033 140
		053	157	078 169
		172	179	158 196
		171	173	
		015	116	020 118
		026	120	052 156
		057		
93	BAYSONIC	105		
94	BAZIN	038	085	073 018
		020	052	053 099
		152	036	005 015
		021	057	084 157
		158	019	
95	BEKO	151	608	125 126
		026	198	141 128
		129	130	131 132
		133	134	153 058
96	BELL & HOWELL	105	582	
97	BEON	036	128	129 130
		131	132	133 134
		153	018	020 052
		053	026	078 140
		156	169	
		196	171	172 173
98	BEST	036	147	151
99	BESTAR	147	036	151
100	BIFONIC	033	019	152 018
		020	052	053
101	BIGSTON	226		
102	BLACK DIAMOND	089		
103	BLACK STRIP	125	126	
104	BLACKTRON	038	144	
105	BLACKWAY	038	026	078 140
		156	169	171 172
		173	196	144
106	BLAMET	019	152	
107	BLAUPUNKT	085	592	052 053
		018	020	208 065
		165	043	109
108	BLAUSONIC	019	152	
109	BLUE SKY	018	085	152 020
		128	156	033 130
		171	038	132 173
		053	134	078 141
		058	140	
		019	099	153 026
		129	169	036 131
		172	052	133 196
		144		
110	BLUE STAR	019	152	036 144
112	BLUEWORLD	038		
113	BONDSTEC	128	129	130 131
		132	133	134 153
		026	078	140 156
		169	171	172 173
		196		
114	BOOTS	031	033	121
115	BORA	019	152	
116	BOSCH	036		
117	BOSTON	146	087	088
118	BPL	143	175	026 078
		140	156	169 171
		172	173	196 144
		026		
119	BRADFORD	105		

Brand of TV

120	BRANDT ELECTRONIQUE	065	005	032	115
		046	064	072	
121	BRENDSTAR	033			
122	BRINKMANN	026	036	140	
123	BRIONVEGA	097	136	146	600
		005	127	026	
124	BRISTOL	146			
125	BROKSONIC	103	579	036	038
126	BROKWOOD	077			
127	BROTHER	141			
128	BRUNOR	128	129	130	131
		132	133	134	153
129	BRUNS	139	005	015	021
		057	084	157	158
		019	152	127	
130	BSR	016	019	021	219
		033	005	226	169
		171	172	173	196
		038	026	078	140
		156	064		
		005	032	115	046
131	BUSH	107	031		
132	BUSH(UK)	005	038	140	018
		052	143	020	058
		152	022	085	169
		031	107	172	036
		121	175		
		015	043	141	019
		053	144	021	078
		156	026	099	171
		033	109	173	226
		196			
133	BUT	005	120	033	171
		078	201	018	141
		038	173	085	020
		157	053	178	114
		117	118		
		015	140	036	172
		084	119	019	156
		052	176	099	021
		158	057	179	116
		058	196		
		026	169	123	124
134	CABLETIME	212	217	610	
135	CADMOS	038			
136	CAMIF	123	124	179	033
		116	117	118	119
		120			
137	CANDLE	045	575		
138	CAPEHART	572	573		
139	CAPSONIC	141	038	031	
140	CARAD	026	078	140	156
		169	171	172	173
		196			
141	CARAT	026	078	140	156
		169	171	172	173
		196			
142	CARENA	018	078	026	141
		038	169	053	172
		020	140	036	156
		052	171	078	173
		196			
143	CARINA	019	152		
144	CARNIVALE	077			
145	CARREFOUR	019	152	018	020
		052	053	089	099
		038	033	114	176
		178	201	116	117
		118	119		
		043	109	085	026
		120	179		
146	CARVER	576	165		
147	CASCADE	226	033	026	
148	CASINO	005	015	021	057

Brand of TV

		084	157	158	
149	CASIO	073	226	026	005
		015			
150	CATHAY	026			
151	CCE	026			
152	CEBIS	019	152		
153	CENTURION	573	026		
154	CENTURY	128	129	130	131
		132	133	134	153
		146	038	033	136
		127			
155	CGE	019	023	024	128
		133	150	151	091
		007	033	036	038
		226	130	131	132
		005	134		
		008	129	153	
156	CGM	090	226	038	141
		058			
157	CHANGHONG	173	141	124	
158	CHAPARRAL	605			
159	CIATE	146			
160	CIE	038	033	226	
161	CIHAN	141			
162	CIMLINE	038	085	099	033
163	CINERAL	192	109		
164	CITIZEN	045	204	573	575
		105	077	571	124
		192	080	202	
165	CITY	033			
166	CLARIVOX	001	147	148	009
		026	019	152	018
		020	052	053	146
167	CLATRONIC	018	020	052	053
		141	038	036	128
		129	130	131	132
		133	134	153	128
		226	130		
		026	151	024	033
		008			
168	CLAYTRON	019	152	038	
169	COLOMBUS	036			
170	COMET	019	152	026	078
		140	156	169	171
		172	173	196	
171	COMPACT	005	015	021	057
		084	157	158	
172	CONCERTO	575	571		
173	CONCORDE	128	129	130	131
		132	133	134	153
		033			
174	CONDOR	005	132	036	151
		019	134	052	153
		026	141	078	169
		129	172	131	196
		130	173		
		018	133	038	152
		020	140	053	156
		033	144	128	171
175	CONFORAMA	005	053	120	169
		018	078	124	172
		020	085	141	175
		026	116	152	196
		118	157		
		015	057	123	171
		019	084	140	173
		021	099	143	179
		033	117	156	052
		119	158		
		038	058		
176	CONIC	005	015	021	057
		084	157	158	
177	CONNEXION	123	033	114	176
		178	201	116	117

Brand of TV

		118	119	120	179
		124			
178	CONRAD	026			
179	CONTEC/CONY	033	574	116	038
		036	019	152	038
		110	226	043	109
		141	026	219	103
		022	105		
180	CONTI	036	026	078	140
		156	169	171	172
		173	196		
181	CONTINENT	038	019	152	026
		078	140	156	169
		171	172	173	196
		033			
182	CONTINENTAL EDISON	065	036	019	152
		005	032	115	046
		064			
183	CORONADO	574			
184	CORVUS	226			
185	COSMEL	038	033	147	026
186	CRAIA	105			
187	CREZAR	226	036		
188	CRISTAL	128	129	130	131
		132	133	134	153
		031			
189	CROSLEY	128	127	576	129
		008	131	024	133
		038	146	153	019
		132	025	134	045
		152	130		
		136	128	005	
190	CROWN	105	141	020	156
		031	173	052	226
		018	151	025	171
		036	196	058	038
		198	140		
		008	143	024	169
		033	175	053	574
		019	152	026	172
191	CRYSTAL	073	085	099	152
		058	019		
192	CS ELECTRONICS	038	026	078	140
		156	169	171	172
		173	196	128	129
		130	131	132	133
		134	153		
193	CTC CLATRONIC	005	131	020	140
		036	157	057	172
		093	018	133	026
		153	052	169	078
		196	129		
		015	132	021	152
		038	158	058	173
		128	019	134	033
		156	053	171	084
		226	130		
194	CTT	128	129	130	131
		132	133	134	153
195	CURSA	089			
196	CURTIS MATHES	045	204	114	176
		178	201		
197	CXC	105			
198	CYMATIC	019	152	019	152
		036			
199	DAEWOO	149	204	604	026
		033	196	058	078
		140	156	169	171
		172	173		
200	DAINICHI	038			
201	DANSAI	038	005	015	021
		057	084	157	158
		089	018	020	052
		053	143	175	033

Brand of TV

		043	109		
		141	125	126	026
202	DANTAX	085	099	151	198
203	DATRONIC	033	033		
204	DATSURA	143	175		
205	DAWA	033	026		
206	DAYTRON	573	204	033	026
207	DE DIETRICH DE VALERIE	038	058		
208	DE GRAAF	143	175	063	060
		005	021		
209	DECCA TATUNG	031	005	015	021
		057	084	157	158
		018	020	052	053
		121	026		
210	DECCA(UK)	002	003	026	028
		031			
211	DEGRAAF	143	175	005	015
		021	057	084	157
		158	107		
212	DEITRON	026			
213	DELTA	031			
214	DEMA COLOR	031	128	129	130
		131	132	133	134
		153			
215	DENKO	141	018	020	052
		053	019	152	
216	DENVER	038	033	198	026
217	DER	122			
218	DESMET	005	130	036	153
		020	134	057	169
		018	132	052	157
		026	146	078	172
		127	196		
		015	131	038	156
		021	140	058	171
		019	133	053	158
		033	152	084	173
		129	128		
219	DIAMANT	026			
220	DIAMOND	141	033		
221	DIGATRON	026			
222	DIGILINE	085	099	018	020
		052	053	026	
223	DIGITAL	038	019	152	
224	DIGITOR	026			
225	DIGIVISION	005	015	021	057
		084	157	158	
226	DIK	141	026		
227	DIXI	033	026	127	
228	DOMEOS	173	036	019	152
		038	196	026	078
		140	156	169	171
		172			
229	DOMOH	036			
230	DOMUS	036			
231	DORIC	018	020	052	053
		116	117	118	119
		120	179	015	110
232	DRS	141	033		
233	DUAL	221	053	011	085
		018	140	026	169
		020	156	041	172
		196	033	171	226
		173	052		
		005	078	015	099
		019	152		
234	DUAL TEC	003	011	019	029
		033			
235	DUMONT	136	572	024	091
		007	031	132	133
		134	153	146	019
		152	038	141	129
		130	131		
		127	036	128	

Brand of TV

236	DUNAI	005			
237	DUNAY	036			
238	DUX	026			
239	D-VISION	026			
240	DWIN	114			
241	DYNASAT	038			
242	DYNATECH	226			
243	DYNATRON	026			
244	EDANLINE	036	026	078	140
		156	169	171	172
		173	196		
245	EDISON	005	032	115	046
		064			
246	ELBE	001	152	009	011
		005	090	151	005
		026	114	176	178
		201			
247	ELCIT	128	129	130	131
		132	133	134	153
		005	127		
248	ELECTRO HOME	575	077	571	572
249	ELECTROTECH	038			
250	ELEKTA	033	026	141	144
251	ELEKTRA	141			
252	ELEKTRONIKA	128	129	130	131
		132	133	134	153
		026	078	140	156
		169	171	172	173
		196			
253	ELEKTRONSKA	019	152		
254	ELG	026			
255	ELIN	005	015	021	026
		033	157	158	057
		084	026	078	140
		156	169	171	172
		173	196		
		038			
256	ELITE	026	078	140	156
		169	171	172	173
		196	099	018	020
		052	053	036	038
257	ELMAN	019	029	033	152
		099	085		
258	ELSAY	026	078	140	156
		169	171	172	173
		196	031		
259	ELTA	018	020	052	053
		226	038	141	033
		078	140	156	169
		171	172	173	196
		026			
260	ELVA	226			
261	EMATEC	005	015	021	057
		084	157	158	
262	EMCO	128	129	130	131
		132	133	134	153
263	EMERSON	103	132	015	157
		084	573	146	036
		172	130	129	134
		021	167	127	582
		152	057		
		105	133	019	158
		123	574	151	038
		173	131	136	140
		024	169	128	005
		153	058		
		196	204	144	026
		171	129	008	156
		078	226		
264	EMPEROR	144			
265	ENGEL	019	152		
266	ENVISION	045	077	571	
267	ERRES	026			
268	ESC	026	078	140	156

Brand of TV

		169	171	172	173
		196	033		
269	ESSAT	038			
270	ESSELTE	226			
271	ESTEL	019	152		
272	ESTELE	005			
273	ETRON	026	033	018	020
		052	053	038	005
274	EUMIG	226			
275	EUREKA	036	033	018	020
		052	053	019	152
		141	026	078	140
		156	169	171	172
		173	196		
276	EUROCOM	019	152	038	
277	EUROFEEL	005	057	019	140
		026	157	171	018
		084	021	156	053
		169	173	196	052
		158	172		
		015	078	020	152
		141			
278	EUROLINE	018	020	052	053
279	EUROMAN	018	020	052	053
		033	141	038	026
		078	140	156	169
		171	172	173	196
		151			
280	EUROPA	026			
281	EUROPHON	000	003	019	029
		030	129	036	033
		026	152	226	073
		005			
282	EXCEL	026			
283	EXPERT	011	005	015	021
		057	084	157	158
284	EXQUISIT	026	038		
285	FAGOR	026	078	140	156
		169	171	172	173
		196			
286	FAMILY LIFE	026			
287	FELIX	038	038	033	
288	FENNER	207	038	033	026
		078	140	156	169
		171	172	173	196
		005	015	021	057
		084	157		
		158			
289	FERGUSON	042	009	005	032
		115	046	064	021
		033	122	065	125
		126	026		
290	FIDELIS	033	036		
291	FIDELITY	107	018	078	052
		053	019	152	226
		085	099	141	021
		026	020	005	
292	FIDELITY(UK)	003			
293	FILMNET	214	602		
294	FILSAI	038			
295	FINLANDIA	005	065	021	107
		031	138	015	084
		025	113	057	143
		157	158	175	
296	FINLUX	142	114	013	133
		026	169	053	199
		128	018	140	031
		172	056	007	130
		021	156		
		150	127	015	134
		029	171	054	005
		129	020	153	034
		173	057	008	131
		024	157		

Brand of TV

		046	196	058	009
		132	025	158	048
		198	078	052	091
		084			
297	FIRST LINE	005	085	134	026
		119	156	018	099
		141	033	128	169
		053	132	175	038
		130	172		
		015	089	140	031
		120	167	019	116
		143	036	129	171
		078	133	179	052
		131	173		
		020	117	152	196
		021	118	153	226
298	FISHER	136	033	221	041
		019	110	031	143
		151	036	015	109
		025	127	152	175
		113	146		
		148	035	005	043
		021			
299	FLEURANCE	089			
300	FLINT	019	131	036	140
		129	156	031	133
		078	152	173	171
		169	033	134	128
		153	196		
		026	132	038	141
		130	172		
301	FLORISTAL	038			
302	FORMENTI	005	078	172	026
		141	015	107	192
		036	157	024	140
		226	057	169	058
		171	158		
		008	084	173	031
		156	021	127	196
		038			
303	FORMENTI-PHOENIX	003	008	025	036
		037	140	024	091
		007	107		
304	FORTRESS	114	176	178	201
		127	146		
305	FRABA	036	019	152	128
		129	130	131	132
		133	134	153	033
		026	078	140	156
		169	171		
		151	172	173	196
306	FRANCE CONCEPT	026	078	140	156
		169	171	172	173
		196			
307	FRANCE TELECOM	228			
308	FREDIKSON	036	018	020	052
		053			
309	FRIAC	033	026	151	
310	FRONTECH	005	129	038	152
		018	131	053	156
		020	133	078	158
		026	140	085	171
		107	173		
		015	130	052	153
		019	132	057	157
		021	134	084	169
		033	141	099	172
		128	196		
311	FS	033	038		
312	FST	031			
313	FUJI	036			
314	FUJITSU	226	019	152	038
		036	058	031	005
		033	026	021	011

Brand of TV

					582
315	FUJITSU GENERAL	033	005		
316	FUNAI	016	141	219	105
		582	005	032	115
		046	064	058	226
		038	085	099	019
		152			
317	FUTRONIC	141			
318	FUTURE	026	036	018	020
		052	053	005	015
		021	057	084	157
		158			
319	FUTURETECH	105			
320	G COLOR	005	015	021	057
		084	157	158	
321	GALAXI	019	152	026	021
		005			
322	GALAXIS	026	131	128	133
		036	132	129	134
		130	151	153	
323	GALAXY	128	129	130	131
		132	133	134	153
324	GALERIA	038	033		
325	GALWAY	026	078	140	156
		169	171	172	173
		196			
326	GBC	002	041	025	140
		038	169	005	107
		031	155	040	172
		196	138	033	156
		173	226		
		003	078	026	152
		039	171	019	
327	GE	573	144	065	
328	GEANT CASINO	005			
329	GEBER	005	015	021	057
		084	157	158	038
330	GEC	005	132	057	156
		130	172	021	134
		084	158	169	196
		031	153	129	171
		140	128		
		015	133	078	157
		131	173	026	
331	GEC(UK)	155			
332	GELOSO	131	038	019	130
		003	128	032	132
		134	153	025	131
		005	129	033	133
		152	107		
		132			
333	GENERAL	036	226	065	
334	GENERAL ELECTRIC	036	065	031	
335	GENERAL TECHNIC	033			
336	GENESIS	033	026		
337	GENEXXA	038	026	078	140
		156	169	171	172
		173	196	005	033
		107			
338	GIBRALTER	045	572		
339	GITEM	018	020	052	053
		038	114	176	178
		201	116	117	118
		119	120	179	033
		123	124		
	GITEM	005	015	021	057
		084	157	158	
340	GM	033			
341	GMG	036	128	129	130
		131	132	133	134
		153	038	038	141
		226	026	078	140
		156	169		
		171	172	173	196

Brand of TV

342	GOLD MEDAL	226			
343	GOLDEN TRADING	026 078 140 156			
		169 171 172 173			
		196			
344	GOLDLINE	026 078 140 156			
		169 171 172 173			
		196 019 152 038			
		147			
345	GOLDSTAR	134 045 576 140			
		026 173 204 063			
		005 156 042 198			
		574 078 021 171			
		024 172			
		153 058 003 151			
		033 196 218 077			
		007 169 575 091			
346	GOLDTECH	019 152 026 078			
		140 156 169 171			
		172 173 196			
347	GOODING	018 020 052 053			
348	GOODMANS	018 125 038 156			
		020 140 052 171			
		085 226 078 196			
		031 152 058 173			
		109 033			
		019 126 043 169			
		026 141 053 172			
		099			
349	GORENJE	038 154 128 129			
		130 131 132 133			
		134 153 151			
350	GORLER JKG	038			
351	GPM	038 026 078 140			
		156 169 171 172			
		173 196			
352	GRADIENTE	077 012 098 165			
		026			
353	GRAETZ	005 015 021 057			
		084 157 158 107			
		026 226			
354	GRANADA	005 107 046 143			
		020 116 056 178			
		008 110 052 158			
		024 118 058 201			
		123 085			
		007 109 048 157			
		021 117 057 179			
		015 113 053 175			
		025 119 061 091			
		124 089			
		031 032 018 114			
		054 176 026 120			
		084 138			
355	GRANADA(UK)	002 003 027 040			
		043 044 046 047			
		048 024 091 007			
		107			
356	GRANDIN	026 078 140 156			
		169 171 172 173			
		196 033 038 085			
		099 141 019 152			
		036 144			
		005			
357	GRONIC	005 038 128 129			
		130 131 132 133			
		134 153			
358	GROSLEY	024 091 007			
359	GRUNDIG	003 044 010 052			
		024 065 008 050			
		020 055 033 091			
		043 049 018 053			
		026 077			
		007			
360	GRUNPY	105 582 058 109			

Brand of TV

		151 058			
361	GTT	033 128 129 130			
		131 132 133 134			
		153 038 173 196			
		026 078 140 156			
		169 171			
		172			
362	HAIER	141			
363	HALIFAX	005 015 021 057			
		084 157 158 141			
		018 020 052 053			
364	HALLMARK	573			
365	HAMMERSTEIN	141			
366	HAMPTON	196 152 226 019			
		033 038 141 026			
		078 140 156 169			
		171 172 173			
367	HANSEATIC	005 057 025 140			
		018 085 033 152			
		015 084 027 151			
		020 091 038 157			
		172 171			
		007 078 026 144			
		019 090 036 156			
		196 054 173 053			
		021 099 043 158			
		052 169			
		024 127 051			
368	HANTAREX	000 019 152 038			
		033 026			
369	HANTOR	038 026			
370	HARLEY DAVIDSON	058			
371	HARMAN KARDON	005			
372	HARVARD	105			
373	HARWOOD	005 015 021 057			
		084 157 158 196			
		033 226 026 078			
		140 156 169 171			
		172 173			
374	HAUPPAUGE	026			
375	HAVEG	018 020 052 053			
		226 005 015 021			
		057 084 157 158			
376	HCM	026 143 173 038			
		156 196 140 171			
		033 144 175 078			
		169 226 141 172			
377	HEDZON	026			
378	HEMA	033			
379	HEMMERMANN	005 084 026 157			
		073 172 019 152			
		056 169 196 038			
		158 078 173 021			
		156 057			
		015 140 171			
380	HEXA	019 152 036 038			
381	HIFIVOX	018 020 052 053			
382	HIGASHI	018 020 052 053			
383	HIGHIWA	038			
384	HIGHLINE	141 026			
385	HIGHTECH	033			
386	HIKONA	038			
387	HINARI	005 059 026 109			
		053 157 018 085			
		038 138 058 175			
		021 099 052 143			
		226 141			
		015 084 033 127			
		057 158 020 089			
		043			
388	HISAWA	018 053 169 026			
		099 173 020 085			
		172 036 144 226			
		038 152 140 196			

Brand of TV

		052	156		
		019	078	171	033
389	HISCHITO	018	020	052	053
390	HISENSE	143	175		
391	HISONIX	038			
392	HIT	127			
393	HITACHI	155	048	029	066
		003	060	033	155
		574	056	031	084
		015	062	040	158
		064	043		
		199	054	030	078
		005	061	039	157
		575	057	032	109
		021	063	041	209
		065	046		
		025	026		
394	HITACHI FUJIAN	061			
395	HITSU	038	018	020	052
		053	026	078	140
		156	169	171	172
		173	196	033	
396	HMV	127			
397	HOME ELECTRONICS	198			
398	HORNYPHON	026			
399	HOSHAI	038	026	078	140
		156	169	171	172
		173	196	144	
400	HUANIU	033			
401	HYPER	134	057	015	152
		033	171	003	084
		021	157	196	024
		007	140	026	169
		158	226		
		173	078	019	156
		038	172	005	091
402	HYPERSONIC	021			
403	HYPSON	018	052	144	020
		078	156	033	099
		171	038	141	173
		169	036	140	172
		226	196		
		019	053	152	026
		085			
404	HYUNDAI	026			
405	IBERIA	026			
406	IBERVISAO	005	015	021	057
		084	157	158	019
		152			
407	IBICO	033			
408	ICE	141	026	226	033
409	ICS	033	038	018	020
		052	053		
410	ICT	026			
411	ID DESIGN	026	078	140	156
		169	171	172	173
		196	005	015	021
		057	084	157	158
412	IEG	018	020	052	053
		019	152		
413	IMA	105			
414	IMPERIAL	128	024	008	129
		150	033	019	131
		005	091	023	134
		038	021	132	007
		153	141		
		133	026	015	130
		151			
415	INCOBE	226	005	015	021
		057	084	157	158
		033	143	175	
416	INDIANA	026			
417	INFINITY	576	026		
418	INGELEN	226	005	015	021

Brand of TV

		057	084	157	158
419	INGERSOLL	038	033		
420	INNO HIT	000	003	031	042
		059	129	156	026
		144	008	024	038
		033	143	175	087
		088			
421	INNOVATION	038	140	026	
422	INTEL	019	152		
423	INTERACTIVE	026	127	078	087
		088	005	021	151
424	INTERBURG	033			
425	INTERBUY	033	141	038	026
		078	140	156	169
		171	172	173	196
		226			
426	INTERDISCOUNT	005	116	053	156
		020	120	084	171
		036	141	201	176
		114	173	052	152
		179	119		
		015	117	057	157
		021	123	089	172
		038	143	226	178
		196	175	078	169
		033	140		
		018	118	058	158
		026	124	019	
427	INTERFUNK	136	052	024	084
		131	156	018	068
		044	127	140	171
		158	021	071	173
		129	151		
		005	053	026	087
		132	157	020	069
		051	128	146	172
		169	021	078	196
		130	153		
		007	057	027	088
		133	015	067	039
		091	134		
428	INTERNAL	033	038	085	099
		026			
429	INTERSOUND	036			
430	INTERVIDEO	226			
431	INTERVISION	005	141	130	036
		169	114	196	020
		152	133	053	173
		201	026	153	134
		058	176		
		018	144	131	038
		171	128	226	033
		156	140	078	178
		019	151	132	052
		172	129		
432	INWAH	033			
433	IPOSTAR	038			
434	IRRADIO	134	059	024	156
		007	091	033	171
		038	173	026	169
		008	140	036	172
		042	196		
		226	078		
435	ISKRA	019	152	053	018
		020	052		
436	ISOSHI	026	078	140	156
		169	171	172	173
		196			
437	ISUKAI	038	026	144	
438	ITC	152	019	036	005
		015	021	057	084
		157	158		
439	ITE	033	019	152	
440	ITL	038	018	020	052

Brand of TV

		053			
441	ITS	038	026	226	144
		141	033		
442	ITT	005	054	143	024
		063	175	015	057
		157	046	091	021
		058	158	048	127
		031	084		
		007	056	154	
443	ITT NOKIA	143	046	015	067
		044	091	157	054
		024	069	072	143
		005	058	039	175
		063	040		
		149	048	021	068
		198	127	158	056
		032	070	073	154
		007			
444	ITV	036	141	026	
445	JANCO	229	216		
446	JANEIL	206			
447	JBL	576	026		
448	JEAN	026	078	140	156
		169	171	172	173
		196	085	099	043
		109			
449	JEC	125	126		
450	JET POINT	033			
451	JMB	085	099	019	152
		033	026	018	020
		052	053		
452	JOHNSON	019	152		
453	JVC	074	043	159	160
		127	168	167	122
		043	109	198	226
		114	176	178	201
454	KABEL	085	099		
455	KAIGE	085	099		
456	KAISUI	144	024	091	007
		033	038	026	078
		140	156	169	171
		172	173	196	
457	KAMACROWN	038			
458	KAMOSONIC	019	152	026	078
		140	156	169	171
		172	173	196	
459	KAMP	572	105		
460	KANSAI	038	226		
461	KAPSCH	011	005	015	021
		057	084	157	158
		143	175	088	019
		152	087		
462	KARCHER	140	091	019	152
		156	141	026	169
		007	151	036	172
		226	171	078	196
		038	173		
		144	033	024	156
		005			
463	KASAI	038			
464	KATHREIN	018	020	052	053
		026			
465	KAWA	226			
466	KAYA	038	026	078	140
		156	169	171	172
		173	196		
467	KB ARISTOCRAT	005			
468	KEC	105			
469	KENDO	129	129	038	151
		171	021	133	085
		157	015	131	078
		153	173	033	140
		128	169		
		005	130	057	152

Brand of TV

		172	026	134	099
		158	019	132	084
		156	196		
470	KENNEDY	025	075	076	036
		005			
471	KENNEX	026	078	140	156
		169	171	172	173
		196	036	226	033
		019	152		
472	KENWOOD	045	077	571	572
473	KERION	038	036	018	020
		052	053		
474	KITON	036	026		
475	KITT	038			
476	KLARMAX	019	152	019	152
		128	129	130	131
		132	133	134	153
		036			
477	KLOSS NOVABEAM	206			
478	KMART	026	078	140	156
		169	171	172	173
		196			
479	KMC	574			
480	KNEISSEL	033	090	038	036
		026	078	140	156
		169	171	172	173
		196	085	099	005
		011	151		
481	KOBIC	033			
482	KOENIG	018	020	052	053
		036			
483	KOLSTER	128	129	130	131
		132	133	134	153
		196	033	019	152
		026	078	140	156
		169	171		
		038	015	172	173
484	KONGWAH	038			
485	KONICHI	033			
486	KONKA	141	038	173	018
		020	052	053	036
		033	226	026	
487	KONTACT	053	018	020	052
488	KORPEL	026			
489	KORTING	136	132	043	151
		130	172	026	134
		127	156	192	038
		146	129	171	196
		128	169		
		138	133	078	153
		131	173	036	140
490	KOSMOS	038	026		
491	KOTRON	226	141		
492	KOYODA	033			
493	KRAKING	019	152		
494	KRONNE	019	152		
495	KTV	574	105	204	045
		026	078	140	156
		169	171	172	173
		196			
496	KUBA	005	015	021	057
		084	157	158	226
497	KUBA ELECTRONIC	015	005		
498	KURO	143	175		
499	KYOSHU	226	026	078	140
		156	169	171	172
		173	196	141	
500	KYOTO	019	152	018	020
		052	053	005	
501	LA MAISON DE VALERIE	018	078	156	033
		119	173	020	117
		171	052	140	196
		179	026	118	172
		053	152		

Brand of TV

		019	116	169	038
		120			
502	LA REDOUTE	018	116	038	123
		085	171	026	118
		053	140	196	173
		036	120	078	169
		226	179		
		020	117	052	124
		099	172	033	119
		058	156		
503	LA SAT	151			
504	LAVIS	033	019	152	
505	LEADER	038	026	078	140
		156	169	171	172
		173	196	033	
506	LECSON	026			
507	LEGEND	038	033		
508	LENCO	164	078	021	157
		057	173	005	140
		033	169	609	226
		019	156	038	172
		036	171		
		207	084	026	158
		613	196	015	152
509	LENOIR	003	033		
510	LES 3 SUISSSES	019	118	176	038
		152	201	033	120
		179	078	169	116
		172	117	140	196
		114	171		
		026	119	178	058
		156	173	036	
511	LESA	128	129	130	131
		132	133	134	153
512	LEVIS AUSTRIA	026			
513	LEYCO	005	057	158	026
		141	173	019	084
		171	036	156	226
		196	021	140	172
		038	157		
		015	078	169	031
		152			
514	LG	026	078	140	156
		169	171	172	173
		196	005	085	099
		141	021	198	151
		033			
515	LIESENK & TTER	018	020	052	053
		026			
516	LIFE	033			
517	LIFETEC	026	140	171	038
		156	173	033	141
		172	078	169	196
		226			
518	LIGHTSTAR	038			
519	LINTON	128	129	130	131
		132	133	134	153
		158	005	015	021
		057	084	157	
520	LLOYD'S	033	226		
521	LME	036	019	152	018
		020	052	053	026
		078	140	156	169
		171	172	173	196
522	LOCATEL	005	015	021	057
		084	157	158	
523	LOEWE	026	078	140	156
		169	171	172	173
		196	036	226	151
		127	090	005	
524	LOEWE OPTA	051	137	169	191
		209	593		
525	LOGIK	026	140	078	171
		118	179	033	169

Brand of TV

		117	173	120	226
		028	156	116	172
		119	196		
		026	078	140	156
		169	171	172	173
		196			
526	LORENSEBO	033			
527	LTV	005	015	021	057
		084	157	158	019
		152			
528	LUMA	032	079	005	015
		021	057	084	157
		158	026	033	011
529	LUMATRON	026	141	005	021
		011			
530	LUX MAY	026	033		
531	LUXMAN	575	077	571	
532	LUXON	226			
533	LUXOR	143	057	024	091
		171	007	078	044
		146	175	018	083
		054	158	082	048
		157	594		
		158	058	026	140
		172	010	081	046
		156	196	021	084
		056	169	032	143
		173	015		
		005	066		
534	LXI	576	077	571	124
		189	026		
535	MADISON	058	141	038	036
		026			
536	MAGNADYNE	000	019	025	029
		056	130	131	132
		136	005	127	128
		129	133	134	153
537	MAGNAFON	000	003	008	029
		030	007	091	024
		036	019	152	018
		020	052	053	
538	MAGNASONIC	085	099		
539	MAGNAVOX	574	576	573	582
		045	043	109	058
		026			
540	MAGNUM	018	020	052	053
		226	026		
541	MAJESTIC	576			
542	MAMMOUTH	036			
543	MANDOR	141			
544	MANESTH	005	058	156	021
		088	172	018	084
		158	036	125	196
		020	087	171	052
		140	141		
		015	078	157	026
		099	173	019	085
		169	038	126	053
		057			
545	MANHATTAN	128	129	130	131
		132	133	134	153
		038	019	152	087
		088	026	078	140
		156	169		
		005	171	172	173
		196			
546	MARANTZ	026	027	576	045
		128	129	130	131
		132	133	134	153
		018	020	052	053
547	MARECH	036			
548	MARELLI	127			
549	MARK	026	033		
550	MARSHALL	038			

Brand of TV

551	MARTIN	107			
552	MASUDA	226	033	141	026
553	MATCH	026	078	140	156
		169	171	172	173
		196	036		
554	MATRIX	036			
555	MATSUI	163	131	021	156
		043	175	085	015
		140	032	170	057
		126	115	172	078
		129	123		
		003	132	026	157
		046	196	099	018
		143	033	171	064
		128	121	173	084
		130	124		
		005	133	028	158
		052	226	109	019
		152	038	031	169
		053	125	113	020
		153	040		
		006	134		
556	MATSUSHITA	170			
557	MAXAM	141			
558	MAXELL	038	226	026	078
		140	156	169	171
		172	173	196	085
		099			
559	MAXI	019	152		
560	MAXIMAL	057	127		
561	MAXIVIDEO	019	152		
562	MAXWELL	005	015	021	057
		084	157	158	128
		129	130	131	132
		133	134	153	019
		152			
563	MB LINE	141			
564	MCE	033			
565	MCM	038			
566	MCMICHAEL	155			
567	MDA	036			
568	MECOA	026	078	140	156
		169	171	172	173
		196			
569	MEDIASCREEN	026	078	140	156
		169	171	172	173
		196	141		
570	MEDIATOR	026			
571	MEDION	033	036	026	038
		085	099	019	152
		140	078		
572	MEGA	038			
573	MEGAS	026	078	140	156
		169	171	172	173
		196			
574	MEGATECH	038	579	077	571
		061			
575	MELECTRONIC	221	073	134	021
		099	156	038	131
		171	015	084	152
		033	129	158	065
		133	173		
		005	078	140	026
		128	157	057	132
		172	019	085	153
		036	130	169	226
		196			
576	MEMOREX	573	575	226	141
		033	170		
577	MEMPHIS	019	152	147	031
		033			
578	MERCURY	026	033		
579	METZ	132	052	019	087
		164	085	026	127

Brand of TV

		152	136	053	020
		088	018	086	034
		144	595		
580	MGA	572	573	582	045
		077	571	162	058
		026			
581	MICROMAXX	038	026		
582	MIDLAND	204			
583	MIKA	038			
584	MINATO	026			
585	MINERVA	007	024	010	050
		020	053	085	008
		044	018	052	091
		065			
586	MINOKA	025	026		
587	MITSUBISHI	135	114	078	005
		171	163	140	113
		032	175	051	201
		045	178	573	169
		572	156		
		136	115	089	026
		172	245	143	196
		043	176	064	224
		046	162	127	109
		028	173		
588	MITSUMI	085	099		
589	MITSURI	128	129	130	131
		132	133	134	153
590	MITSURI GENERAL	005			
591	MIVAR	000	003	090	091
		092	223	007	024
		151	008		
592	MIXER	019	152		
593	MONACO	033			
594	MONDELLO	038	036		
595	MONEXE	226			
596	MONISONIC	033			
597	MORGAN'S	026			
598	MOTION	008	024		
599	MOTOROLA	114	176	178	201
600	MTC	572	131	033	153
		019	140	078	169
		099	173	005	133
		045	157	026	152
		085	172		
		575	132	038	156
		021	151	084	171
		128	196	015	134
		057	158	129	226
		130			
601	MTEC	121			
602	MULTI SYSTEM	140			
603	MULTITEC	026			
604	MULTITECH	105	130	024	156
		008	134	040	171
		020	152	078	153
		132	033	158	018
		141	053		
		151	131	026	157
		015	140	052	172
		021	153	084	005
		133	038	169	019
		151	057		
		173	129	128	093
		196			
605	MULTIVISION	085	099		
606	MURPHY	058	031	005	085
		099	123	124	
607	MURPHY(UK)	040	110		
608	MURUYAMA	085	099		
609	MUSIKLAND	026			
610	MYRYAD	026			
611	NAD	077	571	124	145
		021	005		

Brand of TV

612	NAGOYA	019	152		
613	NAIKO	026	036	038	005
		015	021	057	084
		157	158	128	129
		130	131	132	133
		134	153		
		198			
614	NAKIMURA	033	026	226	
615	NAONIS	005			
616	NEC	165	118	033	156
		078	173	575	120
		038	169	116	196
		026	152	045	172
		171	117		
		572	119	036	165
		109	179	019	140
		043			
617	NECKERMANN	151	130	084	043
		158	018	134	118
		057	173	005	132
		116	053	171	021
		151	120		
		003	131	094	052
		169	020	140	119
		078	179	015	133
		117	054	172	026
		153	127		
		036	156	128	079
		196	038	157	129
618	NEI	005	130	153	033
		133	171	128	147
		196	026	132	169
		078	140	173	129
		152	226		
		019	131	156	038
		134	172		
619	NESCO	058	033	005	015
		021	057	084	157
		158	038		
620	NETSAT	026			
621	NETWORK	147			
622	NEUFUNK	026	033	144	
623	NEWELL	018	020	052	053
		141	026	078	140
		156	169	171	172
		173	196		
624	NEWMAR	153	036	019	152
		128	129	130	131
		132	133	134	
625	NEWORLD	018	020	052	053
626	NEWTECH	038	019	152	026
		033	128	129	130
		131	132	133	134
		153	036	226	
627	NEWVISION	026	078	140	156
		169	171	172	173
		196			
628	NEXT CONCORDE	128	129	130	131
		132	133	134	153
629	NIKKAI	005	132	057	156
		031	141	124	172
		019	134	084	158
		036	147	126	175
		130	153		
		015	133	078	157
		033	143	125	173
		021	137	109	169
		038	152	128	196
		131	129		
		026	140	123	171
		043			
630	NIKKO	045	077	571	192
631	NISHI	033			
632	NOBLEX	033	033	143	175

Brand of TV

		116	117	118	119
		120	179	038	
633	NOBLIKO	129	038	132	019
		128	007	052	134
		024	130	018	091
		153	008	053	152
		029	131		
		003	050	133	020
		129			
634	NOKIA	005	046	084	021
		056	143	015	054
		127	025	058	157
		154	175	198	158
		036	063		
		007	048	091	024
		057			
635	NORDIC	038			
636	NORDING	128	129	130	131
		132	133	134	153
637	NORDMENDE	088	168	005	065
		018	020	052	053
		026			
638	NORDMENE	065	096	097	166
639	NORDWAY	019	152		
640	NORFOLK	019	152	005	
641	NORMEREL	026			
642	NORTEK	026	078	140	156
		169	171	172	173
		196			
643	NORTHSAT	026	078	140	156
		169	171	172	173
		196			
644	NOVAK	026	033	038	018
		020	052	053	
645	NOVATRONIC	033	018	020	052
		053	038	141	026
646	NURNBERG	005	021		
647	OCEANIC (F)	005	061	158	046
		099	173	021	084
		171	054	143	196
		057	157	085	172
		056	156		
		015	078	169	048
		140	175	026	039
		597			
648	OCEANS	026	078	140	156
		169	171	172	173
		196			
649	OCTAL	019	152		
650	ODEON	141	031	140	156
		169	171	172	173
		196	018	020	052
		053	078	026	
651	OEC ELECTRONIC	085	099		
652	OKANO	128	129	130	131
		132	133	134	153
		033	038	141	031
		026	151		
653	OLMAL	019	152		
654	OLYMPUS	018	020	052	053
655	OMEGA	226	141		
656	ONCEAS	033	038	026	078
		140	156	169	171
		172	173	196	
657	ONDIOLA	036			
658	ONWA	018	020	052	053
		033	005	015	021
		057	084	157	158
		226	105	038	
659	OPERA	026	078	140	156
		169	171	172	173
		196	018	020	052
		053	141		
660	OPTALIX	146			

Brand of TV

661	OPTIMUS	145	170		
662	OPTONICA	033	014	114	176
		178	201		
663	ORAVA	036	033		
664	ORBIT	026			
665	ORION	103	032	573	064
		028	167	167	046
		006	099	169	058
		026	141	168	056
		016	115		
		105	036	005	085
		031	224		
666	ORLINE	018	020	052	053
		038	026		
667	ORMOND	038	019	152	026
668	ORSON	038	026	078	140
		156	169	171	172
		173	196	033	
669	ORSOW'E	019	152	128	129
		130	131	132	133
		134	153		
670	OSAKA	085	099		
671	OSAKI	038	026	121	141
		078	140	156	169
		171	172	173	196
		033	226	031	
672	OSIO	026			
673	OSUME	005	031	109	157
		173	021	057	140
		169	196	026	084
		156	172	175	022
		078	143		
674	OSUME	015	043	110	158
		171			
675	OTHERLINE	019	152		
676	OTHERS	185	186	603	
677	OTTOVERSAND	005	117	052	173
		026	156	084	018
		119	054	178	033
		158	099	196	043
		171	114		
		015	118	053	176
		027	157	085	020
		120	057	179	036
		169	109	201	051
		172	116		
		021	140	065	025
		144	078		
678	PACIFIC	026			
679	PAEL	003	008	007	024
		091	018	020	052
		053			
680	PALLADIUM	177	130	057	169
		021	140	116	226
		015	132	084	172
		036	153	127	053
		157	129		
		005	131	078	171
		026	151	117	158
		018	133	085	173
		038	156	128	020
		134	099		
		196	052		
681	PALSONIC	141	026		
682	PALSONIK	033			
683	PANAGOLD	033			
684	PANAMA	018	140	033	169
		078	173	026	156
		053	172	196	217
		020	141	052	171
685	PANASONIC	100	576	026	104
		005	065	102	003
		039	208	021	101
		001	036	170	019

Brand of TV

686	PANAVISION	019	133	078	153
		131	172	033	140
		129	169	196	132
		173	036	152	130
		171	156		
		026	134	128	
687	PANAVOX	073			
688	PANORAMA	226	141	038	
689	PANORAMIC	036	152	019	
690	PARROT	018	020	052	053
691	PATHE CINEMA	005	036	156	018
		090	173	009	053
		171	020	140	196
		026	151	033	152
		024	143		
		007	052	169	019
		091	175	015	078
		172			
692	PAUSA	033	038		
693	PCM	036	038	026	078
		140	156	169	171
		172	173	196	
694	PEACOCK	018	020	052	053
695	PENNY	576	573		
696	PERDIO	024	091	007	033
		149	036	085	099
		019	152	226	031
		144	005	026	
697	PERFEKT	026			
698	PERSHIN	018	020	052	053
699	PHASE	033			
700	PHILARMONIC	018	020	052	053
701	PHILCO	133	021	129	572
		026	133	008	084
		153	150	024	131
		577	036	140	019
		128	158		
		136	023	130	574
		031	134	015	127
		157	151	025	132
		005	057	151	
702	PHILEX	005			
703	PHILIPS	136	024	200	046
		005	091	172	027
		228	053	018	127
		174	033	003	071
		155	149		
		171	026	209	052
		007	115	173	032
		576	064	020	141
704	PHOENIX	036	026	058	151
		005	127	031	
705	PHONOLA	156	149	127	026
706	PILOT	204	077	026	
707	PIONEER	000	027	065	612
		005	015	021	057
		084	157	158	078
		151	026		
708	PIONIER	151			
709	PLANTRON	038	141	033	026
710	POLESTAR	192			
711	POLICOM	086	087	088	021
		005	127		
712	POLYTRON	144			
713	PONTIAC	038			
714	POPPY	033	226		
715	PORTLAND	204	128	084	158
		026	134	574	130
		132	171	057	153
		015	173	078	157
		156	021		
		572	129	196	169
		033	140	005	131
		133	172	058	

Brand of TV

716	POWERPOINT	018	020	052	053
		085	099	026	
717	PRANDONI-PRINCE	008	032	129	007
		024	091	019	152
		036	038	021	
718	PRAXIS	606			
719	PREMIER	033	141		
720	PRIMA	036	026	078	140
		156	169	171	172
		173	196	038	085
		099	033	141	
721	PRINCESS	038			
722	PRINZ	031	019	152	005
		015	021	057	084
		157	158	058	036
		015	021	066	
723	PROEL	128	129	130	131
		132	133	134	153
724	PROFEX	005	140	084	024
		158	131	015	156
		129	033	171	133
		057	173	172	134
		078	196		
		008	153	128	026
		169	132	021	157
		130	038		
725	PROFI	033			
726	PROFITECH	036			
727	PROFITRONIC	019	152	036	033
		026			
728	PROLINE	085	099	141	026
		078	140	156	169
		171	172	173	196
		033	167	031	152
		226			
729	PROSAT	001			
730	PROSCO	033	226		
731	PROSONIC	026	058	018	020
		052	053	226	151
732	PROTECH	005	130	033	141
		019	132	038	147
		026	134	084	153
		021	133	057	152
		129	158		
		015	131	036	144
		128	157		
733	PROTEK	036			
734	PROTON	573	579		
735	PROVISION	036	128	129	130
		131	132	133	134
		153	018	020	052
		053	026		
736	PUCHINI	128	129	130	131
		132	133	134	153
737	PYE	026	015	053	127
		018	020	052	
738	PYGYMY	146	087	088	
739	PYMI	033			
740	QUASAR	019	152	170	033
		038	085	099	
741	QUATTRO	026	078	140	156
		169	171	172	173
		196			
742	QUEEN FIDELITY	033			
743	QUELLE	134	115	020	132
		044	171	067	008
		120	028	143	052
		178	089	018	130
		038	158		
		199	116	021	133
		046	172	073	009
		123	031	152	053
		179	091	019	131
		043	169		

Brand of TV

	QUELLE	003	117	024	134
		049	173	078	010
		124	032	153	053
		196	099	058	110
		065	114		
		005	118	026	140
		050	175	084	013
		128	033	156	057
		201	109	064	129
		036	157		
		007	119	027	141
		051	176	085	015
744	QUESTA	043	109	005	015
		021	057	084	157
		158			
745	R LINE	036	019	152	038
		005	026		
746	RADIALVA	141	038	026	078
		140	156	169	171
		172	173	196	005
		065	147		
747	RADIO SHACK	105	204	036	141
		026			
748	RADIO STEINER	005	140	084	021
		158	118	053	175
		019	156	116	038
		172	123	171	120
		078	196		
		015	143	085	026
		169	119	057	179
		020	157	117	052
		173	124	018	152
		099	033		
749	RADIOLA	209	005	032	115
		046	064	026	
750	RADIOMARELLI	128	129	130	131
		132	133	134	153
		038	026	127	005
		032	115	046	064
751	RADIONETTE	026	058	005	015
		021	057	084	157
		158			
752	RADIOTON	018	020	052	053
		033	038	226	
753	RADIOTONE	026	141	078	171
		036	156	099	173
		226	033	151	085
		172	038	169	140
		196			
754	RANK ARENA	043	109	110	
755	RANK(UK)	022			
756	RBM	018	020	052	053
		005	015	021	057
		084	157	158	
757	RBM(UK)	022	091	018	020
		052	053	031	019
		152			
758	RCA	182	189	572	176
		178	201		
759	REALISTIC	105	575	204	045
760	RECOR	038	036	026	
761	RECTILIGNE	026	038		
762	REDIFFUSION	005	084	043	119
		020	115	053	157
		040	118	598	178
		179	154	032	117
		064	176		
		015	109	046	120
		021	116	057	158
		018	114	052	201
763	REDIFFUSION(UK)	110			
764	REDSTAR	026			
765	REFLEX	026			
766	REGENTE	038			

Brand of TV

767	REVOX	026	078	140	156
		169	171	172	173
		196	151		
768	REX	011	021	032	075
		076	108	127	005
		141			
769	RFT	026	127	169	038
		146	196	031	141
		173	090	156	026
		140	171	078	151
770	RICOH	026			
771	RIZ	019	152		
772	ROADSTAR	026	078	140	156
		169	171	172	173
		196	226	058	033
		038	085	099	141
		019	152		
		033	144		
773	ROBOTRON	127			
774	RODEX	026			
775	ROLLS	033			
776	ROTEL	022			
777	ROWA	036	038	226	033
		141			
778	ROWNSONIC	128	129	130	131
		132	133	134	153
		005	015	021	057
		084	157	158	089
		019	152		
779	ROXY	033			
780	ROYAL LUX	026	078	140	156
		169	171	172	173
		196	151		
781	RUEFACH	026	078	140	156
		169	171	172	173
		196			
782	RUKOPIR	026			
783	S&P	026	078	140	156
		169	171	172	173
		196			
784	SABA	107	033	000	065
		032	088	166	064
		021	082	170	136
		046	005	072	127
		115			
785	SACCS	009			
786	SADEC	038			
787	SAGEM	026	078	140	156
		169	171	172	173
		196	038	144	
788	SAINEL	036			
789	SAISHO	163	028	141	006
		084	158	003	033
		152	019	099	175
		005	057	157	021
		102	226		
		211	031	143	015
		085			
790	SAITO	019	152		
791	SAIVOD	026			
792	SAKAI	026	078	140	156
		169	171	172	173
		196	085	099	005
793	SALORA	143	057	005	079
		047	143	175	064
		021	084	127	158
		229	067	032	230
		073	046		
		158	063	015	083
		054	157	216	066
		025	094	138	175
794	SAMAYTHER	128	129	130	131
		132	133	134	153
795	SAMBERS	000	003	008	029

Brand of TV

		030	042	007	091
		024	036	226	019
		152	033		
796	SAMPO	045	204		
	SAMSUNG	140	573	042	190
		019	152	151	575
		143	204	031	176
		208	201	572	033
		178	005		
797	SAMSUNG	141	574	114	193
		026	175	156	
798	SAMSUX	204	571		
799	SANDOR	005	015	021	057
		084	157	158	
800	SANDRA COLOR	018	020	052	053
		019	152		
801	SANSUI	019	152	038	033
		226	026	572	045
		109			
802	SANTON	033			
803	SANWA	005	015	021	057
		084	157	158	
804	SANYO	111	033	151	072
		013	113	143	058
		183	109	026	022
		175	148	063	005
		110	031		
		112	043	163	090
805	SATRONIC	128	129	130	131
		132	133	134	153
806	SATUM	226			
807	SAVE	026			
808	SAVILLE	085	099		
809	SBR	149	155	026	
810	SCHAUB LORENZ	005	085	036	157
		019	140	057	169
		026	156	078	172
		196	084	173	198
		058	171		
		015	099	038	158
		021	152		
811	SCHNEIDER	221	115	041	021
		140	011	130	064
		032	156	020	134
		099	037	173	038
		196	026		
		226	127	046	024
		149	015	131	078
		033	169	019	133
		091	036	172	039
		226	153		
		005	128	052	025
		152	018	132	085
		035	171	007	129
		053			
812	SCOTCH	077	571		
813	SCOTLAND	019	152	036	005
814	SCOTT	103	105	573	582
		058			
815	SEARS	574	576	573	582
		575	058		
816	SEELVER	026			
817	SEG	026	093	008	024
		005	033	015	109
		141	043		
818	SEI	005	032	115	046
		064	127	015	116
		117	005	026	
819	SEI-SINUDYNE	116	117	026	127
820	SELECO	011	057	075	127
		076	005	226	043
		109	141		
821	SEMP	123			
822	SENCORA	033			

Brand of TV

823	SENTRA	125	126	033	015
824	SERINO	114	176	178	201
825	SHARP	043	053	114	178
		201	203	574	204
		022	065	038	601
		109	176	110	
826	SHINTOSHI	026			
827	SHIVAKI	026			
828	SHORAI	058			
829	SIAREM	000	025	029	136
		005	127		
830	SICATEL	001	009	022	065
831	SIEMENS	018	020	052	053
		010	026	021	110
832	SIERA	026			
833	SIESTA	220	151		
834	SIGNATURE 2000	572	574	573	582
		189	006		
835	SILVA	026	021		
836	SILVER	141	208	043	109
		026	021	058	005
837	SIMPSON	202			
838	SINGER	025	029	130	131
		136	033	127	026
839	SINUDYNE	115	026	005	056
		172	031	015	085
		219	046	021	127
		032	016	099	117
		116	025		
		136	029	006	064
		177			
840	SKANTIC	032			
841	SKY	026	144		
842	SOGERA	036			
843	SOLAVOX	021	031	005	021
		026			
844	SONIKO	026			
845	SONITRON	143	175	151	
846	SONNECLAIR	026			
847	SONOKO	208	033	141	144
		026			
848	SONOLOR	143	175	021	005
		144	116	117	021
849	SONTEC	026	033	151	
850	SONY	028	043	117	118
		119	120	163	179
		224	123	116	110
		043	109	026	
851	SOUND & VISION	026			
852	SOUNDESIGN	058	573	105	582
853	SOUNDWAVE	026	036		
854	SPECTRA	033			
855	SPECTRICON	579	033		
856	SQUARERIEW	095			
857	SSANGYONG	033			
858	SSS	572	105	077	
859	STAKSONIC	033			
860	STANDARD	026	036	033	
861	STARLITE	105	033	005	026
		141			
862	STENWAY	144			
863	STERN	075	127	076	011
		005	141		
864	STRATO	026	141	033	
865	SUNIC LINE	026			
866	SUNKAI	005	032	115	046
		064	167	026	085
		099			
867	SUNSTAR	226	026	141	033
868	SUNWOOD	026	033		
869	SUPER-MACY	204	206		
870	SUPERSONIC	143	175	141	
871	SUPERTECH	033	026		
872	SUPRA	033			

Brand of TV

873	SUPREME	576			
874	SUSUMU	065			
875	SUTRON	033			
876	SYDNEY	146	036	087	088
877	SYLVANIA	576	045	226	
878	SYMPHONIC	226			
879	SYSLINE	036	026	078	140
		156	169	171	172
		173	196		
880	SYSTEL	018	020	052	053
881	SYTONG	038			
882	TACTUS	121			
883	TAISHO	085	099	019	152
884	TAIWAH	018	020	052	053
885	TAMASHI	038			
886	TANDBERG	161	088	026	156
		228	114	078	171
		021	147	087	173
		196	169	005	140
		085	172		
		219	099	038	
887	TANDY	031	015	021	057
		084	157	158	226
		114	176	178	201
		005	065		
888	TAOWAH	196	197		
889	TASHIKO	005	089	171	026
		156	226	019	140
		173	057	158	025
		152	196	084	169
		175	078		
		015	109	172	043
		157	165	021	143
890	TATUNG	002	003	026	028
		031	599	031	121
891	TEAC	078	026	144	226
		015	165	141	033
892	TEAK	026	078	140	156
		169	171	172	173
		196			
893	TEC	005	099	026	157
		019	152	057	171
		084	173	196	015
		147	038	169	085
		196	226		
		011	140	033	158
		021	156	078	172
894	TECHLINE	019	152	026	
895	TECHNEMA	036	089		
896	TECHNICA	038			
897	TECHNICS	170			
898	TECHNISAT	026	005		
899	TECHNOLACE	058			
900	TECHNOVISION	611			
901	TECHWOOD	575	077	571	004
		038			
902	TEDELEX	019	152	198	033
		143	175	026	
903	TEINEL	036	005	015	021
		057	084	157	158
904	TEINELSA	036			
905	TEIRON	033			
906	TEKNANT	036	038		
907	TEKNIKA	572	574	576	105
		582	575	026	078
		140	156	169	171
		172	173	196	058
908	TELE+1	214			
909	TELEAVIA	166	005	032	115
		046	064	072	065
910	TELECOR	026	011	005	
911	TELEFAC	038			
912	TELEFUNKEN	065	166	088	072
		168	165	026	

Brand of TV

913	TELEFUSION	026			
914	TELEGAZI	026	005	011	141
915	TELEMEISTER	128	129	130	131
		132	133	134	153
		036	026		
916	TELEOPTA	226			
917	TELEPAC	018	020	052	053
918	TELERENT	026	078	140	156
		169	171	172	173
		196	033	226	574
919	TELESERVICE	181	212		
920	TELESONIC	019	131	078	152
		036	134	128	169
		130	172	033	133
		099	156	129	171
		196	173		
		026	132	085	153
		038	140		
921	TELESTAR	033	026		
922	TELETECH	026	078	140	156
		169	171	172	173
		196	019	152	141
		038	147	033	085
		099			
923	TELETON	005	015	021	057
		084	157	158	019
		152	087	088	011
		043	109		
924	TELEVIDEON	036	005	116	117
		118	119	120	179
925	TELEVIEW	026			
926	TEMCO	038			
927	TEMPEST	033	026	141	
928	TENFORWARD	026	078	140	156
		169	171	172	173
		196			
929	TENNESSEE	026	078	140	156
		169	171	172	173
		196			
930	TENSAI	018	078	036	156
		020	099	052	171
		033	152	058	173
		196	226	026	140
		053	172		
		019	085	038	169
931	TENSON	036	033	226	005
932	TEPPAZ	005	015	021	057
		084	157	158	
933	TERAFFUK	128	129	130	131
		132	133	134	153
934	TESLA	026	019	152	
935	TETTRAN	036	033		
936	TEVION	196	026	078	140
		156	169	171	172
		173			
937	TEXET	033			
938	THOMSON	166	046	026	072
		156	015	065	033
		088	169	005	064
		032	075	168	
939	THORN	021	113	032	122
		026	117	061	126
		109	025	116	043
		125	031	121	078
940	THORN EMI	005	015	021	057
		084	157	158	018
		020	052	053	
941	THORN FERGUSON	125	126	021	122
942	THORN TELEBANK	005	015	021	057
		084	157	158	
943	THORN-FERGUSON	001	122	141	166
		042	009	005	032
		115	046	064	208
944	TICSONIC	026	078	140	156

Brand of TV

		169	171	172	173
		196			
945	TMK	573	575	165	
946	TOBO	018	020	052	053
		038	033		
947	TOKAI	005	052	026	141
		019	078	033	152
		038	169	196	031
		147	020	140	036
		156	226		
	TOKAI	018	053	173	
948	TOKYO	126	125		
949	TOMASHI	026	078	144	156
		169	171	172	173
		196	038	140	078
950	TOMEI	123	124	226	
951	TOMITA	019	152		
952	TOP SECTOR	038	038		
953	TOP VISION	026	078	140	156
		169	171	172	173
		196	019	152	085
		099	128	129	130
		131	132		
	TOP VISION	133	134	153	
954	TOSHIBA	124	030	091	020
		125	043	123	026
		018	053	139	109
		022	126	052	137
		029	033		
955	TOTEVISION	574			
956	TOWADA	128	129	130	131
		132	133	134	153
		005	015	021	057
		084	157	158	019
		152			
957	TOYODA	033	226	141	
958	TRAKTON	033	141		
959	TRANS CONTINENS	026			
960	TRANSCONTINENT	038	085	099	141
		019	152	196	058
		026	078	140	156
		169	171	172	173
961	TRANSONIC	026	033	078	141
962	TREVI	038	019	152	143
		175	026	078	140
		156	169	171	172
		173	196		
963	TRIAD	026			
964	TRICAL	110			
965	TRIDENT	019	152		
966	TRISTAR	038	141		
967	TRIUMPH	226	085	099	123
		124	026		
968	TSOSCHI	144	038		
969	TVH	141			
970	UHER	221	036	156	024
		078	173	008	049
		171	033	140	196
		011	075	172	035
		151	192		
		007	037	169	026
		091			
971	ULTRAVOX	129	026	130	005
		052	133	018	073
		146	021	084	156
		127	169	172	196
		093	158		
		136	033	131	007
		053	134	019	078
		152	024	091	157
		128	171	173	079
		153	025		
		003	036	132	015
		057	140	020	

Brand of TV

972	UNIC	019	152	018	020
		052	053	143	175
		036			
973	UNIC LINE	015	058	038	156
		026	140	048	171
		056	173	036	152
		054	172	169	196
		078	046		
		019			
974	UNIC RADIO	005	015	021	057
		084	157	158	036
		143	175	019	152
		226			
975	UNIDEN	038			
976	UNITEC	036			
977	UNITED	026	058	141	038
		085	099		
978	UNITRONIC	226			
979	UNIVERSAL	128	129	130	131
		132	133	134	153
		019	152	026	017
		180			
980	UNIVERSUM	141	038	143	109
		175	015	052	153
		118	021	057	165
		129	036	091	173
		133	131		
		199	043	147	110
		179	018	053	156
		119	024	073	169
		130	128	033	084
		172	132		
		005	046	151	116
		196	019	054	157
		120	026	078	171
		140	020	056	158
		152	117		
		008	048		
981	UNIVOX	001	057	147	020
		131	015	128	153
		052	134	009	127
		152	026	133	019
		130	158		
		005	084	152	021
		132	018	129	157
		053	146		
982	URANYA	005	128	157	019
		130	169	026	132
		172	033	134	196
		057	152	084	156
		078	153		
		015	129	158	021
		131	171	031	133
		173	036	140	226
983	UTAX	033	038	018	020
		052	053	033	005
		015	021	057	084
		157	158		
984	VANGUARD	038	005	015	021
		057	084	157	158
985	VECO	033	026	078	140
		156	169	171	172
		173	196		
986	VECTOR RESEARCH	045	077		
987	VEGAVOX	128	129	130	131
		132	133	134	153
		150			
988	VESTEL	173	196	033	036
		128	129	130	131
		132	133	134	153
		038	019	152	026
		078	140		
		026	005	156	169
		171	172		

Brand of TV

989	VEXA	038	033	026	078
		140	156	169	171
		172	173	196	031
990	VIBRANT	121			
991	VICTOR	170	098		
992	VIDAR	005	015	021	057
		084	157	158	
993	VIDEOLOGIC	018	020	052	053
994	VIDEOSYSTEM	026			
995	VIDEOTECHNIC	033	036		
996	VIDEOTON	005	057	158	021
		140	172	019	084
		171	032	156	196
		036	157	169	026
		152	173		
		015	078		
997	VIDIKRON	030	019	152	036
998	VIDION	033			
999	VIDTECH	572	573	077	571
		162	043	109	
1000	VIKING	204	206		
1001	VIPER	147			
1002	VISION	036	026	141	
1003	VISIOREX	128	129	130	131
		132	133	134	153
		019	152		
1004	VISSEAU	019	152		
1005	VISTA	005	015	021	057
		084	157	158	
1006	VISTAR	005	015	021	057
		084	157	158	
1007	VORTEC	065	026		
1008	VOXSON	136	129	031	140
		007	131	046	153
		024	133	078	169
		115	172	128	196
		127	173		
		005	130	032	146
		008	132	064	156
		026	134	091	171
1009	WALTHAM	019	152	036	005
		015	021	057	084
		157	158	033	032
		141	065	026	115
		046	064		
1010	WARDS	572	576	573	582
		575	574	077	058
		180	014		
1011	WATSON	036	033	019	152
		226	026	078	140
		156	169	171	172
		173	196	005	038
1012	WATT RADIO	001	128	025	133
		056	156	196	005
		130	029	140	078
		171	019	132	036
		153	099		
		003	129	026	134
		073	169	173	015
		131	030	152	085
		172			
1013	WEGA	026	043	109	127
1014	WEGA COLOR	043	127		
1015	WEGAVOX	019	130	085	140
		171	033	132	128
		153	173	078	134
		226	169	133	129
		156	196		
		026	131	099	152
		172	038	026	078
		140	156	169	
1016	WELLFUND	033	026	078	140
		156	169	171	172
		173	196		

Brand of TV

1017	WELTBlick	026	036	038	
1018	WEST POINT	128	129	130	131
		132	133	134	153
		026	078	140	156
		169	171	172	173
		196			
1019	WESTON	026	078	140	156
		169	171	172	173
		196	036		
1020	WHARFEDALE	140	018	020	052
		053	026		
1021	WHITE	029	030		
1022	WHITE WESTINGHOUSE	140	129	036	132
		026	131	058	134
		147	128	141	153
		003	130	038	133
1023	WILSON	019	152		
1024	WINDSOR	019	152	038	128
		129	130	131	132
		133	134	153	
1025	WINDSTAR	144	147		
1026	WINSTON	026	078	140	156
		169	171	172	173
		196	038	036	
1027	WINTERNITZ	038	033		
1028	WISI	019	152		
1029	WORLD	085	099		
1030	WORLD TECH	038	033		
1031	XONYCS	038	033		
1032	XRYPTON	036	026		
1033	YAMAHA	045	572		
1034	YAMISHI	038	026	078	140
		156	169	171	172
		173	196	144	
1035	YOKAN	026			
1036	YOKO	140	141	031	169
		019	152	036	172
		078	196	151	033
		171	026	156	038
		173	003		
1037	YORX	018	020	052	053
		033	573		
1038	ZANELA	226			
1039	ZANUS	033			
1040	ZANUSSI	075	005	032	115
		046	064	076	026
1041	ZAWUSSI	005	032	046	064
		115			
1042	ZENITH	181			
1043	ZENOR	143	175		
1044	ZONDA	579	033		
1045	ZOPPAS	005	032	046	064
		115			
1046	ZX	038			

Brand of SAT

NO.	SAT				
1	AB SAT	339	630		
2	AGASHI	275			
3	AKAI	278			
4	ALBA	262	291	339	630
		280	337		
5	ALLANTIDE	337			
6	ALLSAT	245	278		
7	ALLTECH	339	630		
8	ALTAI	264			
9	AMITRONICA	339	630		
10	AMPERE	264			
11	AMSTRAD	231	232	263	338
		284	637	275	339
		630	264	245	636
		619			
12	ANGLO	339	630		
13	ANKARO	233	339	630	280

Brand of SAT

		264			
14	ANTTRON	280			
15	APOLLO	257	280		
16	ARCON	233	277	246	619
		236	345		
17	ARMSTRONG	275	286		
18	ARTIKELNUM	283			
19	ASAT	277			
20	ASLF	339	630		
21	ASSCOM	633			
22	AST	289			
23	ASTHON	317			
24	ASTON	264	245		
25	ASTRA	232	264	338	277
		175	339	630	245
		275			
26	ASTRO	242	335	283	248
27	ATLANTIDE	337			
28	ATLANTIS	280			
29	AUDIOTON	245	280		
30	AURA	284	337		
31	AUSTAR	636			
32	AVALON	264			
33	AXIS	255			
34	BARCOM	233			
35	BENJAMIN	320			
36	BEST	306	233	255	
37	BESTAR	275			
38	BETA	278			
39	BLAUPUNKT	242	335		
40	BLUE SKY	339	630		
41	BOCA	275	339	630	
42	BRAIN WAVE	246			
43	BROCO	339	630		
44	BROECO	339			
45	BSKYB	637			
46	BUBU SAT	339	630		
47	BUSH	291			
48	BUSH(UK)	257			
49	CAMBRIDGE	235	283		
50	CANAL +	633			
51	CANAL SANTE	268			
52	CANAL SATELLITE	633			
53	CARAT. SOM	255			
54	CARDINAL	268			
55	CCI	337			
56	CHAPARRAL	234	266		
57	CHEROKEE	253			
58	CHESS	339	630		
59	CITYCOM	623	342	321	
60	CLATRONIC	246			
61	CLEMENS KAMPHUS	315	337	264	
62	COBRA	264			
63	COLOMBUS	253			
64	COLUMBIA	302			
65	COLUMBUS	273	253		
66	COMMUNICADO	255			
67	COMTEC	255			
68	CONFORAMA	626			
69	CONNEXION	264			
70	CONNEXIONS	264			
71	CONRAD	283			
72	CONRAD ELECTRONIC	339	630		
73	CONTEC	321	255	256	
74	COSAT	245			
75	CROWN	275			
76	CSR	242			
77	DAERYUNG	264			
78	DAEWOO	277	339	630	280
		249			
79	DELFA	636			
80	DEW	255	277		
81	DIGIQUEST	636	623		
82	DISCOVERY	302			

Brand of SAT

83	DISEQC	339			
84	DISK EXPRESS	233			
85	DISTRA	268			
86	DISTRISAT	268	278		
87	DNT	264	282	284	337
		278	277		
88	DRAKE	236	297	299	300
		345	298		
89	DST	280			
90	DUAL	277			
91	DYNASAT	338	342	280	317
		341			
92	ECHOSTAR	237	238	245	264
		266	267	310	312
		346	313	336	234
		630	314	346	339
93	EEC	337			
94	EINHELL	275	280	339	231
		283	520	337	
95	ELAP	339	630		
96	ELSAT	339	630		
97	ELTA	245	280		
98	EMANON	280			
99	EMME ESSE	315	316	317	341
		338	253	342	633
100	ENGEL	339	630		
101	ENTERPRICE	339			
102	EURIEULT	268			
103	EUROCOM	277			
104	EURODEC	628			
105	EUROLINE	339			
106	EUROPA	636	283	278	242
107	EUROSAT	275	245		
108	EUROSKY	275	283	326	282
109	EUROSTAR	317			
110	EUTELSAT	339	630	245	
111	EXATOR	280			
112	FAGOR	245			
113	FAIR MATE	339			
114	FENNER	339	630	277	
115	FERGUSON	626			
116	FIDELITY	231	283	232	
117	FINLUX	334	270		
118	FLAIR MATE	339	630		
119	FORCE	620			
120	FRACARRO	240	233	280	342
		326			
121	FREECOM	280	331	283	242
		335			
122	FTE	256	311	342	249
		287			
123	FTE MAXIMAL	249	339	630	342
		636			
124	FUBA	268	273	233	264
		280	242	335	321
		282	253	315	263
125	GALAXI	233			
126	GALAXIS	636	633	255	245
		623			
127	GALAXISAT	289			
128	GE	626			
129	GITEM	242	264		
130	GIUCAR RECORD	242	271		
131	GMI	275			
132	GOLDBOX	633			
133	GOLDBOX D+	633			
134	GOLDSTAR	331	321		
135	GRANADA	232			
136	GROCOS	275			
137	GROTHUSEN	331			
138	GRUNDIG	242	335	637	257
		283	633		
139	G-SAT	337			
140	HAIER	345			

Brand of SAT

141	HANSEATIC	282			
142	HANTOR	280	246		
143	HARTING & HELLING	337	315		
144	HEPTA	277			
145	HINARI	280			
146	HIRSCHMANN	270	280	264	242
		335	326	337	342
		273	315	283	623
		341	247		
147	HISAWA	246			
148	HITACHI	334			
149	HOUSTON	264	245	246	
150	HUMAX	623	636		
151	HUTH	246	245	255	275
		315	330	331	
152	HYPSON	268			
153	ID DIGITAL	636			
154	IMPERIAL	282			
155	INGELEN	264			
156	INTERDISCOUNT	245	315	636	331
157	INTERNATIONAL	275			
158	INTERTRONIC	275	312		
159	INTERVISION	245			
160	ITALTEL STREAM	637			
161	ITC	339			
162	ITT	257	339		
163	ITT NOKIA	243	244	272	257
164	JEEMON	245			
165	JOHANSSON	246	232	245	
166	JOLLY	245			
167	JSR	245			
168	KAMM	339	630		
169	KATHREIN	247	248	249	273
		322	235	242	335
		321	339	342	337
		630	623	242	341
170	KENWOOD	633			
171	KEY WEST	275			
172	KOLON	280			
173	KOSMOS	235	249	273	331
		315			
174	KREISELMEYER	242	335		
175	KRONOS	249	315	331	
176	K-SAT	339	630		
177	KYOSTAR	254	280		
178	LA SAT	255	275	277	321
		286			
179	LENCO	277	280	331	332
		339	630		
180	LENG	232			
181	LENNOX	245			
182	LENSON	283			
183	LEXUS	278			
184	LG	331			
185	LIFESAT	339	630		
186	LION	337			
187	LOEWE	275			
188	LORRAINE	331			
189	LUXOR	243	250	251	257
		287	283		
190	MACAB	633	242	274	
191	MACOM	297			
192	MAGNAVOX	328			
193	MAGSAT	321			
194	MANATA	339	630		
195	MANHATTAN	245	242	339	246
196	MARRAN	246			
197	MASCOM	273			
198	MASPRO	247	252	257	340
		232	339	630	242
		335			
199	MASTER'S	321			
200	MATAV	249			
201	MATSUI	242	335		

Brand of SAT

202	MAZOU	339			
203	MEDIABOX	633			
204	MEDIAMARKT	275			
205	MEDIASAT	283	633		
206	MEDION	339	630		
207	MEGA	278			
208	MEMPHIS	255			
209	METRONIC	339	630	280	275
		234	287		
		242	335		
210	METZ	337	283	339	630
211	MICRO	337	283	339	630
212	MICRO ELECTRONIC	339	630		
213	MICRO TECHNOLOGY	337	339	630	
214	MICROTEC	339	630		
215	MIKROTECHNIC	337			
216	MINA	344			
217	MINERVA	242	335		
218	MITSUBISHI	339			
219	MONDIAL	268			
220	MORGAN'S	275	339	630	245
		249	619	312	
		239			
221	MOTOROSAT	339			
222	MULTISAT	232			
223	MULTISTAR	249	247	283	
224	MURATO	331			
225	MURATTO	331	289		
226	MYSAT	339	630		
227	NAVEX	246			
228	NEC	276	329	343	293
		282			
229	NECKERMANN	275			
230	NEUHAUS	283	339	630	245
231	NEUSAT	339	630	245	246
232	NEVELING	277			
233	NEWSAT	339			
234	NEWTON	264			
235	NIKKO	275	339	630	286
236	NOKIA	621	622	625	631
		634	257	633	
237	NORDMENDE	280	626	619	
238	NORSAT	282			
239	NORTHSAT	253			
240	NOVIS	246			
241	NTC	315			
242	OBRITECH	280			
243	OCEANIC	337	312		
244	OCTAGON	277	255	280	
245	OKANO	275	315	249	273
246	OLYMPUS	253			
247	OPTEX	321	245	342	253
		268			
248	OPTIMA	315	268		
249	OPTUS	633			
250	ORBISAT	337			
251	ORBIT	277	337		
252	ORBITECH	283	280	282	
253	PACE	257	240	637	633
		268			
254	PALCOM	253	273		
255	PALLADIUM	275	280	283	264
256	PALSAT	277	283	266	256
257	PANASONIC	347	285	637	
258	PANDA	242	335		
259	PANSAT	308			
260	PATRIOT	302			
261	PHILIPS	257	278	279	328
		276	343	633	242
		335	233	637	
262	PHOENIX	255			
263	PHONOTREND	245	315	636	
264	PIONEER	325	633		
265	PK SAT	337			
266	PLANET	264			
267	POLYKON	264			

Brand of SAT

268	POLYTRON	321	264		
269	PREDKI	246	280	302	
270	PREISNER	275	264	282	
271	PREMIER	245	315		
272	PREMIERE	633			
273	PRIMESTAT	307			
274	PROFILE	302			
275	PROSAT	260	304	330	253
276	PROTECH	337			
277	PROTEK	337			
278	PROTON	337			
279	PROVISION	310			
280	QUELLE	242	231	232	
281	RADIO STEINER	245	636	242	289
282	RADIX	264	282	284	337
		321	277		
283	RCA	303			
284	RC-AK	309			
285	REDIFFUSION	293	282	242	
286	REX	339	280		
287	RFT	339			
288	RITAR	286	339		
289	ROADMASTER	339			
290	ROADSTAR	339	630	633	
291	ROCH	268			
292	ROMSAT	280			
293	ROVER	339	630		
294	SABA	626	242		
295	SAGEM	627	628	629	632
296	SAKURA	254	255	283	264
297	SALORA	250	272	257	266
298	SAMSUNG	312	326	327	277
		280	636	633	619
		319	249	339	
299	SAT	283	289	287	231
300	SAT 100	232	338		
301	SAT PARTNER	246	315	280	331
		283			
302	SAT TEAM	339	630		
303	SATEC	339	630		
304	SATECO	280	257		
305	SATELLITE	315			
306	SCHAUB LORENTZ	339			
307	SCHNEIDER	275	289	339	
308	SCHWAIGER	321	636		
309	SCIENTIFIC ATLANTA	305			
310	SEDEA	280	342		
311	SEDEA ELECTRONIQUE	280			
312	SEEMANN	264	275		
313	SEG	280	246		
314	SELECO	245	339	280	
315	SENYU	342	242		
316	SERVI SAT	339	630	245	
317	SIEMENS	242	335		
318	SILVA	331			
319	SINTRACK	281			
320	SKANTIN	339	630		
321	SKINSAT	283			
322	SKY	637	339	630	
323	SKY BIRD	245			
324	SKY DIGIBOX	637			
325	SKYMASTER	339			
326	SKYMASTER	330	339	630	
327	SKYMAX	337			
328	SKYSAT	339	630	283	
329	SKYSAT	283			
330	SKYVISION	245			
331	SL	275			
332	SM ELECTRONIC	339	630		
333	SMART	264	339	630	
334	SONISAT	245	317		
335	SONITRON	245			
336	SONY	324	256	637	633
337	STANDARD	247			

Brand of SAT

338	STAR	322			
339	STARLAND	339	630		
340	STARRING	246			
341	STR	339	275		
342	STREAM	637			
343	STRONG	256	277	280	331
		254	342	633	623
		339	275		
344	STS	252			
345	STV	268			
346	STVI	268			
347	SUMIDA	275			
348	SUNSAT	339	630	245	
349	SUNSTAR	275			
350	TAEYOUNG	280			
351	TAGASHI	275			
352	TAGRA	245			
353	TANTEC	253	273		
354	TECHNILAND	245			
355	TECHNISAT	264	282	283	284
		285	337	266	279
		636			
356	TECHNOSAT	319	245		
357	TECO	277	275		
358	TEDELEX	318			
359	TEKNIKA	323			
360	TELE+	633			
361	TELECOM	339	630	245	283
362	TELEFUNKEN	280			
363	TELEKA	275	273	264	283
		282	249	315	
364	TELEMASTER	310			
365	TELEMAX	286	247	310	
366	TELEMEISTER	255	264	282	284
		322	337		
367	TELESTAR	283			
368	TELESYSTEM	264	342		
369	TELEVES	283			
370	TELEWIRE	245			
371	TENSAI	277	246	283	
372	TERMAL	339			
373	TEVION	339	630		
374	THOMSON	626	630	633	635
		279	637	339	632
375	THORN FERGUSON	257	247	232	
376	THUNDER MAX	278			
377	TIOKO	321	275		
378	TMX	633			
379	TOKAI	278			
380	TONNA	245	283	339	630
		278			
381	TOSHIBA	295	297	242	
382	TPS	632			
383	TRIAD	331	289	337	
384	TRIASAT	283			
385	TRIAx	622	624	242	283
		264	339	630	633
386	TRISTAR	277	256		
387	TURN SAT	339	630		
388	TWINNER	339	630		
389	ULTRAVOX	245			
390	UNIDEN	258	259	261	296
		257	231	327	326
		266			
391	UNISAT	255	275		
392	UNITED SATELLITE	293			
393	UNITOR	233	246		
394	UNIVERSUM	242	335	232	
395	VARIOSAT	242	335		
396	VECTOR	284	337		
397	VIA SAT	632			
398	VICTORSAT	337			
399	VIDEO LINK	338			
400	VIEWSTAR	328			

Brand of SAT

401	VIPER	255			
402	VISIOSAT	339	630	246	
403	VORTEC	254	280	326	619
		312			
404	VTECH	287	289		
405	V-TECH	331	289	287	
406	WELLA	339			
407	WETEKOM	283			
408	WEVASAT	337			
409	WEWA	337			
410	WIBO	275			
411	WINER	246	302		
412	WINERSAT	232	246		
413	WISI	264	274	288	289
		290	291	292	253
		242	335	283	
414	WITTERBERG	232			
415	WORLD	246			
416	WORLDSAT	331			
417	XSAT	339	630	637	
418	ZEHNDER	249	235	289	321
		233			
419	ZENITH	297	299	300	
420	ZODIAC	280			
421	ZWERNASE	275			

Brand of VCR

NO.	VCR				
1	ACCENT	358			
2	ACTION	417			
3	ADELSOUND	364	422		
4	ADMIRAL	368	385		
5	ADVENTURA	222			
6	ADYSON	358			
7	AGASHI	358	402	403	
8	AIM	394			
9	AIWA	222	421	359	398
10	AKAI	349	350	380	381
		418	419	581	402
		403	370	348	359
	AKAI	398	366		
11	AKASHI	358			
12	AKIBA	358			
13	AKURA	358	380		
14	ALBA	394	358	380	394
		398	388		
15	ALBIRAL	402	403		
16	ALLORGAN	366			
17	AMERICAN HIGH	294			
18	AMSTRAD	421	358	394	
19	AMWAY	355			
20	ANITECH	358	402	403	382
21	ANITSCH	382			
22	ANSONIC	364	422		
23	ARISTONA	402	403		
24	ASA	359	402	355	
25	ASBERG	402	403		
26	ASTRO SOUND	402	403		
27	ASUKA	358	384	359	
28	ATLANTIC	359	368	385	
29	AUDIO DYNAMICS	577	384		
30	AUDIOSONIC	358	402	403	394
		359			
31	AUTOVOX	355	359		
32	AVP	398			
33	AWA	359	394	370	
34	BAIRD	350	352	394	387
		368	385		
35	BASIC LINE	358	394	394	387
36	BAUR	362	402	403	
37	BEAULIEU	355			
38	BEKO	387			
39	BESTAR	394			
40	BLACK DIAMOND	370	394		

Brand of VCR

41	BLACK PANTHER	394			
42	BLACKWAY	394			
43	BLAMET	358			
44	BLAUPUNKT	353	354	383	429
		389			
45	BLUE SKY	359	358	398	394
		402	403		
46	BLUE STAR	358			
47	BONDSTEC	358			
48	BONSTEC	358			
49	BRANDT	396	397	389	
50	BRIONVEGA	402	403	387	389
		360			
51	BRUNS	358	382		
52	BSR	414			
53	BUSH	358	380	394	388
		368			
		398	385		
54	BUSH(UK)	362			
55	BUT	396	397	402	403
		394	379	377	406
		383	389	380	359
56	CAMIF	396	397	380	402
		403	379	383	389
		359			
57	CANON	294			
58	CARREFOUR	358	396	397	380
		402	403	370	394
		379	377	406	389
		383			
59	CARVER	294			
60	CATHAY	394			
61	CGE	368	431	421	385
62	CGM	358	359	368	385
63	CIE	358	394	414	
64	CIMLINE	358			
65	CITIZEN	359			
66	CITTAMERCATO	394			
67	CLATRONIC	358	394		
68	COMBITECH	398			
69	CONDOR	402	403	394	368
		385			
70	CONFORAMA	355	359	398	380
		358	396	397	350
		402	403	394	379
		377	406	389	383
71	CONNEXION	396	397	402	403
		377	406		
72	CONTINENT	394			
73	CRAIG	366			
74	CRISTAL	402	403		
75	CROSLEY	294			
76	CROWN	394	358	359	
77	CRYSTAL	402	403		
78	CURTIS MATHES	294			
79	DAEWOO	394	358	402	403
		398	379		
80	DANSAI	358	359	394	
81	DANTAX	398			
82	DAWA	402	403		
83	DAYTRON	394			
84	DBX	577			
85	DE GRAAF	387	377	406	
86	DECCA	374	402	389	398
87	DECCA TATUNG	402	403	370	377
		406	355	398	
88	DECCA VIDEO	355			
89	DECCA(UK)	355	421	402	
90	DE GRAAF	421	406	387	402
		355			
91	DEITRON	394			
92	DEMA COLOR	368	385		
93	DENKO	358			
94	DIAMANT	359			

Brand of VCR

95	DIAMOND	402	403		
96	DIXI	422			
97	DOMOH	359			
98	DUAL	402	403	394	355
		359	356	352	
99	DUMONT	421	387	402	358
		355	368	385	
100	DUX	402	403		
101	DYNATECH	222	421		
102	DYNATRON	402	403	359	
103	EDANLINE	368	385		
104	EDISON	358			
105	ELBE	384	394	379	359
		368	385		
106	ELCATECH	358			
107	ELIN	366	368	385	
108	ELSAY	358			
109	ELTA	358	394		
110	EMERSON	424	222	421	359
		399	358	368	385
		379			
111	ERRES	359	402	403	
112	ESC	402	403	394	366
113	ESSELTE	358			
114	ESTELLE	402	403		
115	ETSUKO	358			
116	EUMIG	368	385		
117	EUREKA	402	403		
118	EUROMAN	402	403		
119	EUROPHON	402	403		
120	EXCEL	368	385		
121	FAIR VIDEO	359			
122	FENNER	358	402	403	
123	FERGUSON	396	397	394	359
		378			
124	FIDELITY	358	366	398	421
125	FINLANDIA	387	402	355	368
		385	377	406	359
		370			
126	FINLUX	355	421	377	350
		387	368	359	402
		394	406	357	385
127	FIRST LINE	358	402	403	370
		394	388	379	359
128	FISHER	357	368	387	385
		386	384		
129	FLINT	402	403		
130	FORMENTI	402	403	394	359
131	FORMENTI-PHOENIX	359	402		
132	FRABA	402	403		
133	FRONTECH	358	382		
134	FUJI	294			
135	FUJITSU GENERAL	359			
136	FUNAI	421	580	222	358
		414			
137	GALAXI	359			
138	GALAXIS	394	359		
139	GALWAY	394			
140	GARRARD	222			
141	GBC	358	402	403	394
142	GCM	402	403		
143	GE	294	396		
144	GEC	402	403	355	
145	GEC(UK)	355	402		
146	GELOSO	358	394		
147	GENERAL	420	358		
148	GENEXXA	359	387		
149	GITEM	358	396	397	380
		350	402	403	370
		394	359	379	383
		389	377	406	355
150	GOLDHAND	358	382		
151	GOLD MEDAL	358			
152	GOLDSTAR	359	362	384	396

Brand of VCR

		397	402	403
153	GOODMANS	376	394	421 366
		358	398	359 388
154	GPX	359		
155	GRAETZ	387	377	406 366
		368	385	
156	GRANADA	402	403	370 394
		379	377	406 355
		368	385	387 366
	GRANADA	359		
157	GRANADA(UK)	355	433	429 362
		406	387	368 360
		402		
158	GRANDIN	358	394	359 398
159	GRONIC	358	402	403
160	GRUNDIG	402	396	388 358
		398	409	
161	HAMPTON	358		
162	HANIMEX	398		
163	HANSEATIC	355	362	402 403
		358	359	384 394
164	HANTAREX	402	403	359
165	HARLEY DAVIDSON	222		
166	HARMAN KARDON	384		
167	HARWOOD	358		
168	HAVEG	387	383	389 355
169	HCM	358	382	388
170	HINARI	358	363	422 388
		394	398	382 364
		366		
171	HISAWA	358	398	
172	HISCHITO	379	348	419
173	HITACHI	352	358	362 365
		222	421	366 387
174	HOHER	394		
175	HYPER	358	402	403 394
176	HYPSON	358	394	
177	IMPERIAL	359	366	368 385
		421	431	
178	INGERSOLL	364	422	366
179	INNO HIT	366	358	402 403
		394		
180	INTERBUY	358	359	
181	INTERDISCOUNT	368	385	358 401
		396	397	380 350
		402	403	370 394
		389	355	359 387
		379	377	406
182	INTERFUNK	355	367	402 403
		387		
183	INTERNAL	394	398	
184	INTERNATIONAL	394	359	
185	INTERVIDEO	359		
186	INTERVISION	358	350	394 359
		383	389	384
187	INWA	394		
188	IRRADIO	359	358	394 387
		368	385	417
189	ITT	387	368	380 358
		350	394	366 377
		406	359	368 385
190	ITT NOKIA	377	406	349 352
		367	429	368 369
		350		
191	ITV	394	359	
192	JENSEN	581		
193	JMB	398		
194	JVC	349	352	369 390
		389	392	395 581
		577	378	
195	KAISER	402	403	
196	KAISUI	358		
197	KAMBROOK	359		
198	KANSAI	358		

Brand of VCR

199	KAPSCH	402	403	
200	KARCHER	362	366	402 394
201	KENDO	380	350	358 359
		394		
202	KENNEX	358	394	
203	KENWOOD	581	577	368 384
204	KIMARI	357		
205	KNEISSEL	394	359	398
206	KODAK	294		
207	KORPEL	358		
208	KORTING	355		
209	KRONNE	384		
210	KUBA	358	386	368 385
		357		
211	KUBA ELECTRONIC	357		
212	KUNYA	389		
213	KYOTO	358		
214	LA MAISON DE VALERIE	396	397	380 402
		403	394	379 377
		406	383	359
215	LA REDOUTE	383	389	358 359
		398	396	397 380
		350	402	403 370
		394	379	
216	LAVIS	358		
217	LENCO	394	417	358 394
218	LENOIR	402	403	368 385
219	LES 3 SUISES	396	397	380 402
		403	377	406 383
		355	359	401
220	LEYCO	358		
221	LG	359	394	
222	LIESENKOTTER	402	403	
223	LLOYD	421		
224	LOCATEL	402	403	
225	LOEWE OPTA	355	429	402 383
		359	364	422
226	LOGIK	422	393	366 358
		364		
227	LLOYD	222		
228	LUMA	393	394	
229	LUMATRON	394		
230	LUX MAY	358		
231	LUXON	358		
232	LUXOR	362	368	350 387
		377	406	385 370
		358	357	380
233	LXI	580	222	
235	MAGNADYNE	402	403	368 385
236	MAGNASONIC	368	385	
237	MAGNAVOX	294	580	
238	MANESTH	358	359	379
239	MARANTZ	429	355	376 577
		294	359	384 402
		403		
240	MARK	359	394	
241	MARQUANT	358	382	
242	MARTA	359		
243	MASTER'S	394		
244	MATSUI	422	393	399 362
		359	402	403 398
		414	368	385 364
		366		
245	MAXEL	358		
246	MAXIMAL	368	385	
247	MEDIATOR	402	403	
248	MEDION	350	398	
249	MEI	294		
250	MELETRONIC	358	359	384
251	MEMOREX	359	580	222 294
		421	406	387 368
		357	385	377
252	MEMPHIS	358		
253	METZ	354	371	429 430

Brand of VCR

		383			
254	MIGROS	389			
255	MIKA	359			
256	MINERVA	354	429		
257	MITSUBISHI	355	358	370	389
		424	430	402	
258	MOTOROLA	294			
259	MTC	222	421	366	
260	MULTITECH	358	394	222	421
		402	403	394	359
		387			
261	MURPHY	421			
262	NAD	424	387		
263	NATIONAL	383			
264	NEC	352	384	389	581
		577	387	359	394
265	NECKERMANN	349	352	355	362
		363	429	366	368
		402	380	403	385
		387	414		
266	NECOLA	359			
267	NEI	402	403	355	359
268	NESCO	358	398		
269	NEUFUNK	359			
270	NIKKAI	358	402	403	394
		359	417		
271	NIKKEI	359			
272	NOBLIKO	429			
273	NOKIA	387	368	350	394
		366	377	406	385
		380			
274	NORDMENDE	349	352	356	369
		372	389	390	392
		395	396	397	373
275	NORMEREL	402	403		
276	OCEANIC	350	402	403	387
		377	406	368	385
		406			
277	OKANO	358	394	380	
278	OLYMPUS	294			
279	OPTONICA	406			
280	ORBIT	358			
281	ORION	363	393	398	399
		400	422	414	364
282	OSAKA	414	359	421	358
		402	403		
283	OSIO	359			
284	OSUME	358	402	403	388
285	OTHERS	412	413	414	415
286	OTTOVERSAND	355	362	402	403
		384			
287	PACE	398			
288	PALLADIUM	350	418	358	380
		359	364	422	366
		402	403	355	384
	PALLADIUM	368	385		
289	PALSONIC	358			
290	PANASONIC	353	367	383	416
		294			
291	PANAVISION	402	403		
292	PANORAMA	359			
293	PATHE CINEMA	370	364	422	
294	PCM	359			
295	PENNEY	384	577	294	
296	PENTAX	365			
297	PERDIO	421			
298	PHILCO	358	384	368	385
		294			
299	PHILIPS	294	355	377	401
		402	403	429	358
		406	359		
300	PHOENIX	402	403	394	359
		368	385		
301	PHONOLA	355	402	403	

Brand of VCR

302	PILOT	359			
303	PIONEER	355	389	401	403
		424	425	426	577
		402	383		
304	PLAYSONIC	368	385		
305	PORTLAND	394			
306	PRINZ	387			
307	PROFEX	358	355		
308	PROFITRONIC	366			
309	PROLINE	421	358	396	397
		394	388		
310	PROSCO	394	359		
311	PROSONIC	394			
312	PROTECH	394			
313	PROVISION	394			
314	PYE	402	403	355	389
315	QUARTZ	368	385		
316	QUASAR	294	359	394	
317	QUELLE	354	355	363	374
		429	366	359	402
		414	368	385	358
	QUELLE	350	403		
318	RADIALVA	358	377	406	359
319	RADIO SHACK	222			
320	RADIO STEINER	389	355	348	419
		398	368	385	380
		396	397	402	403
	RADIO STEINER	383	394	379	377
		406			
321	RADIOLA	402	403	355	
322	RADIOMARELLI	359	368	385	
323	RADIONETTE	359			
324	RAFAL	359			
325	RBM	358			
326	RCA	405	396		
327	REALISTIC	580	222	294	421
		406	366	387	368
		359			
328	RECOR	402	403		
329	REDIFFUSION	402	403	383	
330	REOC	394			
331	REX	352	369	390	380
		394	389	359	
332	RFT	358	382		
333	ROADSTAR	358	394	366	359
334	ROBERTS	402	403		
335	ROYAL	358			
336	SABA	349	352	356	369
		389	390	392	396
		397	394		
337	SADEC	417			
338	SAISHO	424	422	393	399
		398	364		
339	SALORA	350	370	394	387
		377	406	362	368
		385			
340	SAMBERS	359			
341	SAMSUNG	366	348	402	403
342	SANSUI	389	581	577	358
343	SANWA	364	422		
344	SANYO	387	357	377	389
		406	404	368	385
345	SAVANA	359			
346	SAVILLE	398	394	366	
347	SBR	402			
348	SCAN SONIC	366			
349	SCHAUB LORENZ	358	350	394	387
		380	359	368	
350	SCHNEIDER	355	358	366	421
		359	402	403	370
		394	398		
351	SEARCH	359			
352	SEARS	386	294		
353	SEAWAY	394			

Brand of VCR

354	SEG	358	369	366	394
		387	382		
355	SEI	364	422		
356	SEIGA	370			
357	SEI-SINUDYNE	422	364		
358	SELECO	380	394	359	389
359	SENTA	431			
360	SENTRA	358	359	388	
361	SENYU	380	379	377	406
		355			
362	SETRON	358	359		
363	SHARP	376	406	377	355
		386	359		
364	SHINKO	358			
365	SHINTON	418	358	387	
366	SHIVAKI	402	403	359	
367	SHIWAN	358			
368	SHORAI	414	364	422	
369	SIEMENS	429	354	368	387
		389	359	386	385
370	SIGNATURE	580			
371	SILMA	402	403		
372	SILVA	358	359		
373	SILVER	394	368	385	
374	SINGER	396	397	394	368
		379	385		
375	SINUDYNE	355	422	402	403
		398	414	364	
376	SOLAVOX	368	385		
377	SONIKO	358			
378	SONITRON	359	357		
379	SONNECLAIR	358			
380	SONOKO	402	403	394	387
381	SONOLOR	387	377	406	385
		368			
382	SONTEC	402	403	394	359
383	SONY	294	374	375	405
		407	408	409	428
		421			
384	SOUNDWAVE	359			
385	SOUNDZONE	398			
386	SPECIAL	359			
387	SSANGYONG	358			
388	STANDARD	402	403	394	
389	STARLITE	359	387		
390	STERN	394	389		
391	STM	368	385		
392	SUNKAI	399	394	414	
393	SUNSTAR	421			
394	SUNWOOD	358			
395	SUPRA	358	402	403	394
		366			
396	SYLVANIA	222	294	421	
397	SYMPHONIC	222	580	421	358
398	T+A	383			
399	TAISHO	364	422	398	
400	TANDBERG	393	394		
401	TANDY	368	385		
402	TASHIKO	421	406	358	355
		359	377	366	
403	TATUNG	355	581	421	402
		403	370	377	406
		398			
404	TEAC	222	581	580	421
		358	394	359	
405	TEAK	355			
406	TEC	358	402	403	394
		387			
407	TECHLINE	358			
408	TECHNEMA	370			
409	TECHNICS	294			
410	TEDELEX	359			
411	TEKNIKA	222	421	359	
412	TEKVIS	359			

Brand of VCR

413	TELEAVIA	389			
414	TELEFUNKEN	349	352	356	369
		389	390	392	397
		410	396	394	
415	TELEMEISTER	421			
416	TELERENT	359			
417	TELESONIC	402	403		
418	TELESTAR	359			
419	TELETECH	358	394		
420	TELEVIDEON	368	385		
421	TENOSAL	358			
422	TENSAI	358	402	403	359
		364	422	394	
423	TEXET	394			
424	THOMAS	222	294		
425	THOMSON	349	352	356	369
		389	395	396	397
426	THORN	378	387	359	
427	THORN FERGUSON	358	396	397	402
		403	370	394	387
		389	355	359	348
		419	368	385	349
		352	378	390	396
428	TMK	363			
429	TOKAI	358	402	403	359
		387			
430	TOKIWA	358			
431	TONSAI	358			
432	TORRE	387			
433	TOSHIBA	352	369	379	358
		355	398	370	
434	TOTEVISION	366	359		
435	TOWADA	358	382		
436	TOWIDA	358			
437	TRACK	350			
438	TREDEX	394			
439	TRIAD	394			
440	TWINNER	358			
441	UHER	352	366	359	
442	ULTRAVOX	358	394		
443	UNIC LINE	358			
444	UNITECH	366			
445	UNITED	394	398		
446	UNITED QUICK STAR	394			
447	UNIVERSUM	350	359	366	387
448	UNIVOX	402	403		
449	URANYA	359	368	385	
450	VECTOR	384			
451	VECTOR RESEARCH	577	384		
452	VECTOR RESSEARCH	384			
453	VEXA	394			
454	VICTOR	389	395	369	581
		577			
455	VIDEO	384			
456	VIDEO CONCEPTS	577			
457	VIDEO ELECTRCLUB	368	385		
458	VIDEOSEC	358			
459	VIDEOSONIC	222			
460	VIDEOTECHNIK	358			
461	VIDION	394	368	385	
462	WALTHAM	402	403		
463	WARDS	222	294	580	
464	WATSON	394	398		
465	WATT RADIO	394	387		
466	WEGAVOX	402	403		
467	WELTBlick	394	359		
468	WHITE WESTINGHOUSE	359	394	384	368
		385			
469	WORLD	398			
470	XENON	393			
471	XR-1000	222	294		
472	YAMAHA	581	577	384	
473	YAMISHI	358	394	359	
474	YOKAN	358			

Brand of VCR

475	YOKO	366	359	358	382
476	ZANELA	358			
477	ZX	398			

Brand of CABLE**NO. CABLE**

1	ABC	305			
2	AEON	438			
3	APO	452			
4	ASIAGIANT	437	449		
5	BEST	435			
6	EASTERN	443	444	446	
7	GMI	451	454	455	
8	IIEC	442	450		
9	JEBSEE	434			
10	KOKA	438	441		
11	OAK	436			
12	OMEGA	578			
13	SIGNAL	578			
14	SKYGIANT	447	448		
15	STARCOM	578			
16	STARGATE	578			
17	STARQUEST	578			
18	TADA	301	457		
19	TAICOM	438			
20	TAY SHOEN	442	453		
21	TOSHIBA	456			
22	TUSA	578			
23	WINER	437			
24	WISO	439	440		

Brand of DVD**No. DVD**

1	3DLAB	669			
2	AFREEY	601			
3	AIWA	597	682	683	
4	AKAI	671	681		
5	ALBA	609	682	692	693
		678			
6	AMSTRAD	693			
7	A-TREND	694			
8	AUDIOSONIC	617			
9	BBG	556			
10	BLAUPUNKT	678			
11	BLUE SKY	602	682	693	
12	BUSH	678	681	682	690
		692	559	609	617
13	BUT	558	568	584	585
		594	609	639	660
		669	687	692	709
		714			
14	CAMOS	696	712		
15	CARREFOUR	689	717	712	696
16	CGV	559			
17	CINEULTRA	692			
18	COMWELL	605			
19	CONFORAMA	558	584	585	594
		614	639	660	669
		671	680	696	709
		712	714		
20	CYBER HOME	601	694		
21	CYTRON	683			
22	DAEWOO	651	683		
23	DENON	561	642	665	700
		710	561	583	592
		601	642	656	706
		695			
24	DENVER	692			
25	DENZEL	680			
26	DIGIRED	678			
27	DIVIDO	683			
28	DUAL	680			
29	ELTA	617	681		
30	EMERSON	683			

Brand of DVD

31	ENZER	680			
32	GE	678			
33	GITEM	558	568	584	585
		594	614	639	660
		669	671	680	687
		689	696	709	712
		714	717		
34	GOLDSTAR	712	696	699	703
35	GOODMANS	559	681		
36	GRAETZ	680			
37	GRUNDIG	585	683	669	682
38	HANRMAN KARDON	606	714	676	
39	HDT	683			
40	HITACHI	563	588	589	590
		675	680		
41	HITEKER	599	602		
42	HOYO	673			
43	INTEGRA	673			
44	IRRADIO	587			
45	ISP	682			
46	JBL	676			
47	JEKEN	609	692		
48	JMB	682			
49	JVC	558	562	586	659
		669	688	716	708
50	KENWOOD	665	668	700	584
		585	592	594	616
		639	669	714	
51	KISS	680			
52	KLH	565			
53	KONKA	693			
54	LA MAISON DE VALERIE	568	687	696	712
55	LA REDOUTE	568	584	585	594
		639	669	687	689
		714	717		
56	LASONIC	673			
57	LAWSON	683			
58	LENCO	609	692		
59	LENOXX	681			
60	LES 3 SUISES	687	568	584	585
		594	639	669	714
		712	696		
61	LEXIA	609	692		
62	LG	712	696		
63	LOEWE OPTA	585	594	669	
64	LOGIX	683			
65	LUMATRON	683			
66	LUXMAN	590			
67	MAGNAVOX	558			
68	MAKAMICHI	612			
69	MANHATTAN	683	693		
70	MARANTZ	584	585	594	639
		669	714		
71	MATSUI	682			
72	MBO	681			
73	METZ	689	717		
74	MICROMAXX	682			
75	MICROMEDIA	669			
76	MICROMEGA	669			
77	MITSUBISHI	701	685	697	
78	MONYKA	680			
79	NAD	613			
80	NAIKO	651			
81	NAKAMICHI	671			
82	NAKAMICHI	671			
83	NEUFUNK	680			
84	OMNI	681			
85	ONKYO	558	641	672	673
		596			
86	OPTIMUS	686	666		
87	ORION	682			
88	OTHERS	567	603		
89	PAITE	614			
90	PALLADIUM	682			

Brand of DVD

91	PANASONIC	557	561	592	649
		650	656	657	658
		665	677	695	700
		706	707		
92	PHILCO	559			
93	PHILIPS	584	585	594	639
		669	714	558	674
94	PHONOTREND	692			
95	PIONEER	689	717	640	618
		713	588	644	655
		686			
96	POINTER	651			
97	PROVISION	692			
98	QUELLE	712	696	693	
99	RADIO STEINER	561	568	656	665
		687	695	700	706
		558	660	709	
100	RADIO SHACK	691			
101	RAITE	680			
102	RCA/PROSCAN	691	560		
103	REC	690	665	700	
104	REDIFFUSION	561	656	665	695
		700	706		
105	REPLAY	645			
106	REVOY	585	609	692	
107	ROADSTAR	607	690	692	681
108	ROTEL	586	688		
109	SAMSUNG	590	665		
110	SANSUI	682			
111	SANYO	682			
112	SCAN	683			
113	SCHAUB LORENZ	585			
114	SCHNEIDER	683			
115	SCOTT	602			
116	SEG	693	601	680	
117	SHANGAI	602			
118	SHARP	566	682	957	970
119	SHERWOOD	678			
120	SHINCO	569	570	678	645
121	SINGER	681			
122	SINUDYNE	595			
123	SKYWORTH	604			
124	SM ELECTRONIC	681	617	681	
125	SONY	702	638	646	647
		648	652	653	654
		662	667	698	704
		705	711	593	615
126	SYLVANIA	643	663	664	
127	TEAC	588	678		
128	TECHNICS	561	656	665	695
		700	706	677	
129	TELEFUNKEN	687	568		
130	TENSAI	617	681		
131	TEONICS	700			
132	THETA DIGITAL	717			
133	THOMSON	568	687	591	
134	TOKAI	614	680		
135	TOSHIBA	558	660	661	709
136	TRILEC	617	681		
137	UNITED	609	692		
138	UNIVERSUM	712	696	693	
139	UNK	598			
140	WESDER	609	692		
141	WESTWOOD	693			
142	WMM NETSTATION	608	610	611	
143	XBOX	560			
144	YAMAHA	561	592	600	670
		715	561	656	665
		695	700	706	
145	YAMAKAWA	679	684		
146	ZENITH	564	558		

Brand of HIFI

NO. HIFI

1	FISHER	463				
2	HITACHI	464				
3	KENWOOD	461	465	466	467	468
4	LENCO	526	527	528	529	530
		531	532			
5	NORDMENDE	482				
6	ONKYO	469	470			
7	PANASONIC	471				
8	PIONEER	478				
9	SANYO	472				
10	SHARP	465				
11	SHERWOOD	473	474	508	509	
12	SONY	548				
13	TECHNICS	475				
14	YAMAHA	476	477			

Brand of CD

NO. CD

1	AIWA	512				
2	ATLE	528				
3	DENON	480				
4	FISHER	479				
5	HAITAI	481				
6	INKEI	474				
7	JBL	554	555			
8	JVC	536				
9	KARCHER	482				
10	KENWOOD	483	511			
11	LENCO	531	482			
12	LUXOR	462				
13	MAGNAVOX	486	507	535		
14	MISSION	486				
15	NEC	484				
16	ONKYO	544	545	546	547	
17	PHILIPS	485	486	510	535	
18	PIONEER	487	488	541		
19	PROTON	486				
20	RADIOTONE	482				
21	ROTEL	486	513	514		
22	SAE	486				
23	SANSUI	534				
24	SANYO	535	537			
25	SHARP	483	499			
26	SONY	489	490	506	538	
27	SYLVANIA	486	535			
28	TEAC	539	542			
29	TECHNICS	491				
30	VICTOR	536				
31	YAMAHA	543				

Brand of LD

NO. LD

1	KENWOOD	503				
2	MAGNAVOX	502				
3	PANASONIC	504	505			
4	PHILIPS	492				
5	PIONEER	502				
6	RCA	533				
7	SONY	506				
8	TOSHIBA	502				
9	ZENITH	501				

Brand of AUX

No. AUX

1	CABLETIME	458	459	460(CTV)		
2	CARAVELL	553(VCD)				
3	DENON	497(TUNE)	499(DECK)			
4	LENCO	516	517	518	519	520
	LENCO	521	522	523	524	525 (CD)
5	PHILIPS	493(EQ)	494(PIP)	495(TAPE)	498(TUNE)	500(DCC)
6	ROTEL	515(TAPE)				
7	SONY	496(TAPE)	506(CDV)	549(TUNE)		